



# OPTIDRIVE™

**AC Variable Speed Drive**  
**0.37kW – 22kW / 0.5HP – 30HP**  
**110 – 480 Volt 1 & 3 Phase**

**Advanced Technical Manual**



**This Document is for use with version 3.02 Firmware.**

Invertek Drives Ltd adopts a policy of continuous improvement and whilst every effort has been made to provide accurate and up to date information, the information contained in this User Guide should be used for guidance purposes only and does not form the part of any contract.

The information in this user guide relates to the functionality of the firmware version as stated above. Prior versions of firmware may not fully support all functions as described. If necessary firmware updates may be carried out using Optitools Studio PC software.

**Revision History**

Issue	Note	Section	Date
01	Pre Release		05/01/16
02	Added changes for V3.02 Firmware P-30 new functions P00-47 New functions Revised I/O table P-15 selection Added parameter changes for 1 Phase Output Drive Added Voltage levels for 110V drives Revised Fire Mode Operation Description Added CAN & Modbus info for new P-30	N/A 1.3.2 1.5 1.6 1.4 7.11 1.7.1 3.5.8	04/02/16
03	Updated P-11 Max setting to "Drive Dependent" Updated P-18 Maximum Setting = 9 Updated P-25 Added setting 11 Updated P-30 Correcting error to Index 3 Updated P-51 adding setting 5 Updated P-52 description to add note regarding setting 5 for P-51 Updated I/O function tables to improve clarity	1.3.1 1.3.2 1.3.2 1.3.2 1.3.3 1.3.3 1.6.3	

<b>1. Optidrive E3 Parameter Set Overview .....</b>	<b>5</b>
1.1. About this section .....	5
1.2. Parameter Structure Overview .....	5
1.3. Parameter Descriptions .....	6
1.4. Alternative Parameter Functions for Single Phase Output Drives .....	13
1.5. Parameter Group 0 – Monitoring Parameters (Read Only) .....	14
1.6. Control Terminal Connections .....	15
1.7. Software Functions .....	20
<b>2. Drive Model Specific Parameter Variations .....</b>	<b>21</b>
2.1. Available Effective Switching Frequency Options .....	21
2.2. V/F Mode Voltage Boost Setting Options .....	22
<b>3. Fieldbus Interface Support.....</b>	<b>23</b>
3.1. Fieldbus Support Overview .....	23
3.2. Modbus RTU.....	23
3.3. CAN Open.....	23
3.4. Parameter Access Overview .....	26
3.5. Additional Information.....	29
3.6. Modbus RTU Indirect Parameter Access.....	31
<b>4. Diagnostic and Fault Messages .....</b>	<b>32</b>
<b>5. Rated Temperatures and De-rating curves .....</b>	<b>33</b>
5.1. Thermal Management .....	33
5.2. De-rating Curves Explained .....	33
5.3. Derating Graphs .....	33
<b>6. Immunity Tests .....</b>	<b>41</b>
6.1. Electrostatic Discharge (ESD) .....	41
6.2. Electrical Fast Transient Burst (EFT/B) .....	41
6.3. Surge .....	41
6.4. Dielectric strength (Flash) .....	41
<b>7. General Technical and Performance Data.....</b>	<b>42</b>
7.1. Electrical Data .....	42
7.2. Input Output Current Ratings .....	42
7.3. Standby Power Consumption.....	43
7.4. DC Bus Discharge Time.....	44
7.5. Earth Leakage Current (Touch Current) .....	44
7.6. Digital & Analog I/O .....	44
7.7. Environmental Data .....	45
7.8. Response Times .....	45
7.9. Motor Control Performance .....	45
7.10. Output Current Limit.....	45
7.11. Under / Over Voltage Trip Levels .....	46

# 1. Optidrive E3 Parameter Set Overview

---

## 1.1. About this section

This document provides a list of the available parameters, and a description of their respective functions, for the Optidrive E3.

## 1.2. Parameter Structure Overview

The parameter set is arranged in Groups according to the following structure

Parameter Group	Range	Access Level	Access Type
P00	P00-01 to P00-20	Extended	Read Only
	P00-21 to P00-50	Advanced	Read Only
Basic Parameters	P-01 to P-14	Basic	Read / Write
Extended Parameters	P-15 to P-50	Extended	Read / Write
Advanced Parameters	P-51 to P-60	Advanced	Read / Write

Access to all parameter groups is controlled by setting P-14 as follows

P-14 = P-37 (Factory setting: 101) Allows Extended Parameter Access

P-14 = P-37 + 100 (Factory Setting: 201) Allows Advanced Parameter Access

## 1.3. Parameter Descriptions

### 1.3.1. Basic Parameters

Par.	Description	Minimum	Maximum	Default	Units	
P-01	<b>Maximum Frequency / Speed Limit</b>	P-02	500.0	50.0 (60.0)	Hz / RPM	
	Maximum output frequency or motor speed limit – Hz or RPM. If P-10 >0, the value entered / displayed is in RPM The maximum possible value is limited by the lower of the following :- - 500.0Hz maximum limit - If P-10 >0, (500 x 120) / Motor Poles RPM - P-17 / 16 Hz <b>Note</b> When P-10>0, slip compensation is automatically enabled, and P-01 is corrected to the synchronous speed of the motor.					
P-02	<b>Minimum Frequency / Speed Limit</b>	0.0	P-01	0.0	Hz / RPM	
	Minimum speed limit – Hz or RPM. If P-10 >0, the value entered / displayed is in RPM					
P-03	<b>Acceleration Ramp Time</b>	0.00	600.0	5.0	s	
	Acceleration ramp time from zero Hz / RPM to base frequency (P-09) in seconds.					
P-04	<b>Deceleration Ramp Time</b>	0.00	600.0	5.0	s	
	Deceleration ramp time from base frequency (P-09) to standstill in seconds. When set to 0.00, the value of P-24 is used.					
P-05	<b>Stopping Mode</b>		0	3	0	-
	<b>Setting</b>	<b>Description</b>	<b>Behaviour on Disable (Stop)</b>		<b>Behaviour on Mains Loss</b>	
	0	Ramp To Stop with Mains Loss Ride Through.	Ramp to stop, rate controlled by P-04.		Continue running by reducing the speed of the load to recover energy.	
	1	Coast to Stop	Coast (freewheel) to stop			
	2	Ramp To Stop	Ramp to stop, rate controlled by P-04.	Ramp to stop using the P-24 decel ramp		
3	AC Flux Braking	As setting 2, but AC flux braking is also applied, increasing the level of available braking torque.	As setting 2, but AC flux braking is also applied, increasing the level of available braking torque.			
P-06	<b>Energy Optimiser</b>		0	1	0	-
	<b>Setting</b>	<b>Function</b>	<b>Description</b>			
	0	Disabled				
1	Enabled	When enabled, the Energy Optimiser attempts to reduce the overall energy consumed by the drive and motor by reducing the output voltage during constant speed, light load operation. The Energy Optimiser is intended for applications where the drive may operate for some periods of time with constant speed and light motor load, whether constant or variable torque.				
P-07	<b>Motor Rated Voltage / Back EMF at rated speed (PM / BLDC)</b>	0	250 / 500	230 / 400	V	
	For Induction Motors, this parameter should be set to the rated (nameplate) voltage of the motor (Volts). For Permanent Magnet or Brushless DC Motors, it should be set to the Back EMF at rated speed.					
P-08	<b>Motor Rated Current</b>	Drive Rating Dependent			A	
	This parameter should be set to the rated (nameplate) current of the motor. This parameter cannot be adjusted greater than the continuous current rating of the drive. When the motor nameplate value is entered, thermal overload protection is enabled, as described in section 7.10.4					
P-09	<b>Motor Rated Frequency</b>	25	500	50 (60)	Hz	
	This parameter should be set to the rated (nameplate) frequency of the motor					
P-10	<b>Motor Rated Speed</b>	0	30000	0	RPM	
	This parameter can optionally be set to the rated (nameplate) RPM of the motor. When set to the default value of zero, all speed related parameters are displayed in Hz, and the slip compensation for the motor is disabled. Entering the value from the motor nameplate enables the slip compensation function, and the Optidrive display will now show motor speed in estimated RPM. All speed related parameters, such as Minimum and Maximum Speed, Preset Speeds etc. will also be displayed in RPM. <b>Note</b> If P-09 value is changed, P-10 value is reset to 0.					
P-11	<b>Low Frequency Torque Boost Current</b>	0.0	Drive Dependent	3.0	%	
	Low Frequency Torque Boost is used to increase the applied motor voltage and hence current at low output frequencies. This can improve low speed and starting torque. Increasing the boost level will increase motor current at low speed, which may result in the motor temperature rising - force ventilation of the motor may then be required. In general, the lower the motor power, the higher the boost setting that may be safely used. For IM motors, when P-51 = 0 1 or 1, a suitable setting can usually be found by operating the motor under very low or no load conditions at approximately 5Hz, and adjusting P-11 until the motor current is approximately the magnetising current (if known) or in the range shown below. Frame Size 1 : 60 – 80% of motor rated current Frame Size 2 : 50 – 60% of motor rated current Frame Size 3 : 40 – 50% of motor rated current Frame Size 4 : 35 – 45% of motor rated current This parameter is also effective when using alternative motor types, P-51 = 2, 3 or 4. In this case, the boost current level is defined as 4*P-11*P-08					

Par.	Description	Minimum	Maximum	Default	Units
P-12	<b>Primary Command Source</b>	0	6	0	-
	<b>Setting</b>	<b>Function</b>	<b>Description</b>		
	0	<b>Terminal Control</b>	The drive responds directly to signals applied to the control terminals.		
	1	<b>Uni-directional Keypad Control</b>	The drive can be controlled in the forward direction only using an external or remote Keypad		
	2	<b>Bi-directional Keypad Control</b>	The drive can be controlled in the forward and reverse directions using an external or remote Keypad. Pressing the keypad START button toggles between forward and reverse.		
	3	<b>Modbus Network Control</b>	Control via Modbus RTU (RS485) using the internal Accel / Decel ramps		
	4	<b>Modbus Network Control</b>	Control via Modbus RTU (RS485) interface with Accel / Decel ramps updated via Modbus		
	5	<b>PI Control</b>	User PI control with external feedback signal		
	6	<b>PI Analog Summation Control</b>	PI control with external feedback signal and summation with analog input 1		
	7	<b>CAN open Control</b>	Control via CAN (RS485) using the internal Accel / Decel ramps		
	8	<b>CAN open Control</b>	Control via CAN (RS485) interface with Accel / Decel ramps updated via CAN		
9	<b>Slave Mode</b>	Control via a connected Invertek drive in Master Mode. Slave drive address must be > 1.			
<b>NOTE</b> When P-12 = 1, 2, 3, 4, 7, 8 or 9, an enable signal must still be provided at the control terminals, digital input 1					
P-13	<b>Operating Mode Select</b>	0	2	0	-
	<b>Setting</b>	<b>Function</b>	<b>Description</b>		
	0	<b>General Purpose</b>	Intended for most standard applications, parameters are configured for constant torque operation with 150% overload allowed for 60 seconds, spin start is disabled.		
	1	<b>Pump Mode</b>	Intended for pump applications, parameters are configured for variable torque operation with 110% overload allowed for 60 seconds, spin start is disabled.		
2	<b>Fan Mode</b>	Intended for Fan applications, parameters are configured for variable torque operation with 110% overload allowed for 60 seconds, spin start is enabled.			
P-14	<b>Extended Menu Access code</b>	0	65535	0	-
	Enables access to Extended and Advanced Parameter Groups. This parameter must be set to the value programmed in P-37 (default: 101) to view and adjust Extended Parameters and value of P-37 + 100 to view and adjust Advanced Parameters. The code may be changed by the user in P-37 if desired.				

## 1.3.2. Extended parameters

Par.	Description	Minimum	Maximum	Default	Units
P-15	<b>Digital Input Function Select</b>	0	15	0	-
	Defines the function of the digital inputs depending on the control mode setting in P-12. See section 1.6 Control Terminal Connections for more information.				
P-16	<b>Analog Input 1 Signal Format</b>	See Below		U0-10	-
	<b>Setting</b>	<b>Function</b>	<b>Description</b>		
	U 0-10	0 to 10V Uni-direction	The drive will remain at P-01 if the analog reference after scaling and offset are applied is $\leq 0.0\%$		
	b 0-10	0 to 10V bi-directional	The drive will operate the motor in the reverse direction of rotation if the analog reference after scaling and offset are applied is $< 0.0\%$		
	A 0-20	0 to 20mA			
	t 4-20	4 to 20mA	The drive will trip and show the fault code <b>4-20F</b> if the signal level falls below 3mA		
	r 4-20	4 to 20mA	The drive will run at Preset Speed 1 (P-20) if the signal level falls below 3mA		
	t 20-4	20 to 4mA	The drive will trip and show the fault code <b>4-20F</b> if the signal level falls below 3mA		
	r 20-4	20 to 4mA	The drive will run at Preset Speed 1 (P-20) if the signal level falls below 3mA		
U 10-0	10 to 0V	The drive will operate at Maximum Frequency / Speed if the analog reference after scaling and offset are applied is $\leq 0.0\%$			
P-17	<b>Maximum Effective Switching Frequency</b>	4	32	8	kHz
Sets maximum effective switching frequency of the drive. If "rEd" is displayed, the switching frequency has been reduced to the level in P00-32 due to excessive drive heatsink temperature.					
P-18	<b>Output Relay Function Select</b>	0	9	1	-
	Selects the function assigned to the relay output. The relay has two output terminals, Logic 1 indicates the relay is active, and therefore terminals 10 and 11 will be connected.				
	<b>Setting</b>	<b>Function</b>	<b>Logic 1 when</b>		
	0	Drive Enabled (Running)	The motor is enabled		
	1	Drive Healthy	Power is applied to the drive and no fault exists		
	2	At Target Frequency (Speed)	The output frequency matches the setpoint frequency		
	3	Drive Tripped	The drive is in a fault condition		
	4	Output Frequency $\geq$ Limit	The output frequency exceeds the adjustable limit set in P-19		
	5	Output Current $\geq$ Limit	The motor current exceeds the adjustable limit set in P-19		
	6	Output Frequency $<$ Limit	The output frequency is below the adjustable limit set in P-19		
	7	Output Current $<$ Limit	The motor current is below the adjustable limit set in P-19		
8	Analog Input 2 $>$ Limit	The signal applied to analog input 2 exceeds the adjustable limit set in P-19			
9	Drive Ready to Run	The drive is ready to run, no trip present.			
P-19	<b>Relay Threshold Level</b>	0.0	200.0	100.0	%
Adjustable threshold level used in conjunction with settings 4 to 7 of P-18					
P-20	<b>Preset Frequency / Speed 1</b>	P-02	P-01	5.0	Hz / RPM
P-21	<b>Preset Frequency / Speed 2</b>	P-02	P-01	25.0	Hz / RPM
P-22	<b>Preset Frequency / Speed 3</b>	P-02	P-01	40.0	Hz / RPM
P-23	<b>Preset Frequency / Speed 4</b>	P-02	P-01	P-09	Hz / RPM
Preset Speeds / Frequencies selected by digital inputs depending on the setting of P-15 If P-10 = 0, the values are entered as Hz. If P-10 > 0, the values are entered as RPM.					
<b>Note</b> Changing the value of P-09 will reset all values to factory default settings					
P-24	<b>2nd Deceleration Ramp Time (Fast Stop)</b>	0.00	600.0	0.00	s
This parameter allows an alternative deceleration ramp down time to be programmed into the Optidrive, which can be selected by digital inputs (dependent on the setting of P-15) or selected automatically in the case of a mains power loss if P-05 = 2 or 3. When set to 0.00, the drive will coast to stop.					
P-25	<b>Analog Output Function Select</b>	0	11	8	-
	<b>Digital Output Mode. Logic 1 = +24V DC</b>				
	<b>Setting</b>	<b>Function</b>	<b>Logic 1 when...</b>		
	0	Drive Enabled (Running)	The Optidrive is enabled (Running)		
	1	Drive Healthy	No Fault condition exists on the drive		
	2	At Target Frequency (Speed)	The drive is in a fault condition		
	3	Drive Tripped			
	4	Output Frequency $\geq$ Limit	The output frequency exceeds the adjustable limit set in P-19		
	5	Output Current $\geq$ Limit	The motor current exceeds the adjustable limit set in P-19		
	6	Output Frequency $<$ Limit	The output frequency is below the adjustable limit set in P-19		
	7	Output Current $<$ Limit	The motor current is below the adjustable limit set in P-19		
	<b>Analog Output Mode</b>				
	<b>Setting</b>	<b>Description</b>	<b>Range</b>		
	8	Output Frequency (Motor Speed)	0 to P-01, resolution 0.1Hz		
	9	Output (Motor) Current	0 to 200.0% of P-08, updated every 256ms		
10	Output Power	0 – 200.0% of drive rated power			
11	Load Current (Torque)	0 – 200.0% of P-08, updated every 64ms			

Par.	Description	Minimum	Maximum	Default	Units	
P-26	<b>Skip frequency hysteresis band</b>	0.0	P-01	0.0	Hz / RPM	
P-27	<b>Skip Frequency Centre Point</b>	0.0	P-01	0.0	Hz / RPM	
	The Skip Frequency function is used to avoid the Optidrive operating at a certain output frequency, for example at a frequency which causes mechanical resonance in a particular machine. Parameter P-27 defines the centre point of the skip frequency band, and is used in conjunction with P-26. The Optidrive output frequency will ramp through the defined band at the rates set in P-03 and P-04 respectively, and will not hold any output frequency within the defined band. If the frequency reference applied to the drive is within the band, the Optidrive output frequency will remain at the upper or lower limit of the band.					
P-28	<b>V/F Characteristic Adjustment Voltage</b>	0	250 / 500	0	V	
P-29	<b>V/F Characteristic Adjustment Frequency</b>	0.0	P-09	0.0	Hz	
	This parameter in conjunction with P-28 sets a frequency point at which the voltage set in P-29 is applied to the motor. Care must be taken to avoid overheating and damaging the motor when using this feature.					
P-30	<b>Start Mode, Automatic Restart, Fire Mode Configuration</b>					
	<b>Index 1 : Start Mode &amp; Automatic Restart</b>					
	Selects whether the drive should start automatically if the enable input is present and latched during power on. Also configures the Automatic Restart function.					
	<b>Setting</b>	<b>Start Function</b>	<b>Auto Restarts</b>	<b>Description</b>		
	<i>Ed9E-r</i>	Edge Run	0	Following Power on or reset, the drive will not start if Digital Input 1 remains closed. The Input must be closed after a power on or reset to start the drive.		
	<i>RUto-0</i>	Auto	0	Following a Power On or Reset, the drive will automatically start if Digital Input 1 is closed.		
	<i>RUto-1</i>	Auto	1	As <i>RUto-0</i> . In addition, following a trip, the drive will make up to 5 attempts to restart at 20 second intervals. The numbers of restart attempts are counted, and if the drive fails to start on the final attempt, the drive will trip with a fault, and will require the user to manually reset the fault. The drive must be powered down to reset the counter.		
	<i>RUto-2</i>	Auto	2			
	<i>RUto-3</i>	Auto	3			
	<i>RUto-4</i>	Auto	4			
	<i>RUto-5</i>	Auto	5			
	<b>Index 2 : Fire Mode Input Logic</b>					
			0	1	0	-
	Defines the operating logic when a setting of P-15 is used which includes Fire Mode, e.g. settings 15, 16 & 17.					
	<b>Setting</b>	<b>Input Type</b>	<b>Fire Mode Active When</b>			
	0	Normally Closed (NC)	Input is open			
	1	Normally Open (NO)	Input is closed			
	<b>Index 3 : Fire Mode Input Type</b>					
			0	1	0	-
	Defines the input type when a setting of P-15 is used which includes Fire Mode, e.g. settings 15, 16 & 17.					
	<b>Setting</b>	<b>Input Type</b>	<b>Description</b>			
	0	Maintained Input	The drive will remain in Fire Mode, only as long the fire mode input signal remains (Normally Open or Normally Closed operation is supported depending on Index 2 setting).			
	1	Momentary Input	Fire Mode is activated by a momentary signal on the input. Normally Open or Normally Closed operation is supported depending on Index 2 setting. The drive will remain in Fire Mode until disabled or powered off.			
P-31	<b>Keypad Start Mode Select</b>	0	3	1	-	
	This parameter is active only when operating in Keypad Control Mode (P-12 = 1 or 2) or Modbus Mode (P-12 = 3 or 4). When settings 0 or 1 are used, the Keypad Start and Stop keys are active, and control terminals 1 and 2 must be linked together. Settings 2 and 3 allow the drive to be started from the control terminals directly, and the keypad Start and Stop keys are ignored.					
	<b>Setting</b>	<b>Start At</b>	<b>Enable From</b>			
	0	Minimum Speed	Keypad			
	1	Previous Speed	Keypad			
	2	Minimum Speed	Terminal			
	3	Previous Speed	Terminal			
	4	Present Speed	Keypad			
	5	Preset Speed 4 (P-23)	Keypad			
	6	Present Speed	Terminal			
	7	Preset Speed 4 (P-23)	Terminal			
P-32	<b>Index 1 : Duration</b>	0.0	25.0	0.0	s	
	<b>Index 2 : DC Injection Mode</b>					
			0	2	0	-
	<b>Index 1:</b> Defines the time for which a DC current is injected into the motor. DC Injection current level may be adjusted in P-59.					
	<b>Index 2:</b> Configures the DC Injection Function as follows :-					
	<b>Setting</b>	<b>Function</b>	<b>Description</b>			
	0	DC Injection on Stop	DC is injected into the motor at the current level set in P-59 following a stop command, after the output frequency has reached 0.0Hz for the time set in Index 1. This can be useful to ensure the motor has reached a complete stop before the drive disables.			
	1	DC Injection on Start	DC is injected into the motor at the current level set in P-59 for the time set in Index 1 immediately after the drive is enabled, prior to the output frequency ramping up. The output stage remains active during this phase. This can be used to ensure the motor is at standstill prior to starting.			
	2	DC Injection on Start & Stop	DC injection applied as both settings 0 and 1 above.			



Par.	Description	Minimum	Maximum	Default	Units	
P-33	<b>Spin Start (S2 &amp; S3 Only) / DC Injection Time On Start (S1 Only)</b>		0	2	0	-
	<b>Setting</b>	<b>Function</b>	<b>Description</b>			
	0	Disabled				
	1	Enabled	When enabled, on start up the drive will attempt to determine if the motor is already rotating, and will begin to control the motor from its current speed. A short delay may be observed when starting motors which are not turning.			
	2	Enabled on Trip, Brown Out or Coast Stop	Spin start is only activated following the events listed, otherwise it is disabled.			
P-34	<b>Brake Chopper Enable (Not Size 1)</b>		0	2	0	-
	<b>Setting</b>	<b>Function</b>	<b>Description</b>			
	0	Disabled				
	1	Enabled With Software Protection	Enables the internal brake chopper with software protection for a 200W continuous rated resistor			
	2	Enabled Without Software Protection	Enables the internal brake chopper without software protection. An external thermal protection device should be fitted			
	3	Enabled With Software Protection	As setting 1, however the Brake Chopper is only enabled during a change of the frequency setpoint, and is disabled during constant speed operation			
	4	Enabled Without Software Protection	As setting 2, however the Brake Chopper is only enabled during a change of the frequency setpoint, and is disabled during constant speed operation.			
P-35	<b>Analog Input 1 Scaling / Slave Speed Scaling</b>		0.0	2000.0	100.0	%
	<p><b>Analog Input 1 Scaling.</b> The analog input signal level is multiplied by this factor, e.g. if P-16 is set for a 0 – 10V signal, and the scaling factor is set to 200.0%, a 5 volt input will result in the drive running at maximum frequency / speed (P-01)</p> <p><b>Slave Speed Scaling.</b> When operating in Slave Mode (P-12 = 9), the operating speed of the drive will be the Master speed multiplied by this factor, limited by the minimum and maximum speeds.</p>					
P-36	<b>Serial Communications Configuration</b>		See Below			
	<b>Index 1 : Address</b>		0	63	1	-
	<b>Index 2 : Baud Rate</b>		9.6	1000	115.2	kbps
	<b>Index 3 : Communication loss protection</b>		0	3000	300	ms
	This parameter has three sub settings used to configure the Modbus RTU Serial Communications. The Sub Parameters are					
	<b>Index 1 : Drive Address :</b> Range : 0 – 63, default : 1					
	<b>Index 2 : Baud Rate &amp; Network type :</b> Selects the baud rate and network type for the internal RS485 communication port. For Modbus RTU : Baud rates 9.6, 19.2, 38.4, 57.6, 115.2 kbps are available. For CAN Open : Baud rates 125, 250, 500 & 1000 kbps are available.					
<b>Index 3 : Watchdog Timeout :</b> Defines the time for which the drive will operate without receiving a valid command telegram to Register 1 (Drive Control Word) after the drive has been enabled. Setting 0 disables the Watchdog timer. Setting a value of 30, 100, 1000, or 3000 defines the time limit in milliseconds for operation. A 't' suffix selects trip on loss of communication. An 'r' suffix means that the drive will coast stop (output immediately disabled) but will not trip.						
P-37	<b>Access Code Definition</b>		0	9999	101	-
	Defines the access code which must be entered in P-14 to access parameters above P-14					
P-38	<b>Parameter Access Lock</b>		0	1	0	-
	<b>Setting</b>	<b>Function</b>	<b>Description</b>			
	0	Unlocked	All parameters can be accessed and changed			
	1	Locked	Parameter values can be displayed, but cannot be changed except P-38.			
P-39	<b>Analog Input 1 Offset</b>		-500.0	500.0	0.0	%
	Sets an offset, as a percentage of the full scale range of the input, which is applied to the analog input signal. This parameter operates in conjunction with P-35, and the resultant value can be displayed in P00-01. The resultant value is defined as a percentage, according to the following :- $P00-01 = (\text{Applied Signal Level}(\%) - P-39) \times P-35$					
P-40	<b>Index 1 : Display Scaling Factor</b>		0	3	0	-
	<b>Index 2 : Display Scaling Source</b>		0.000	16.000	0.000	-
	Allows the user to program the Optidrive to display an alternative output unit scaled from either output frequency (Hz), Motor Speed (RPM) or the signal level of PI feedback when operating in PI Mode.					
	<b>Index 1 :</b> Used to set the scaling multiplier. The chosen source value is multiplied by this factor.					
	<b>Index 2 :</b> Defines the scaling source as follows :-					
	<b>Setting</b>	<b>Function</b>	<b>Description</b>			
	0	Motor Speed	Scaling is applied to the output frequency if P-10 = 0, or motor RPM if P-10 > 0.			
1	Motor Current	Scaling is applied to the motor current value (Amps)				
2	Analog Input 2 Signal Level	Scaling is applied to analog input 2 signal level, internally represented as 0 – 100.0%				
	3	PI Feedback	Scaling is applied to the PI feedback selected by P-46, internally represented as 0 – 100.0%			
P-41	<b>PI Controller Proportional Gain</b>		0.0	30.0	1.0	-
	PI Controller Proportional Gain. Higher values provide a greater change in the drive output frequency in response to small changes in the feedback signal. Too high a value can cause instability					
P-42	<b>PI Controller Integral Time</b>		0.0	30.0	1.0	s
	PI Controller Integral Time. Larger values provide a more damped response for systems where the overall process responds slowly					

Par.	Description	Minimum	Maximum	Default	Units
P-43	<b>PI Controller Operating Mode</b>	0	1	0	-
	<b>Setting</b>	<b>Function</b>	<b>Description</b>		
	0	Direct Operation	Use this mode if when the feedback signal drops, the motor speed should increase.		
	1	Inverse Operation	Use this mode if when the feedback signal drops, the motor speed should decrease.		
P-44	<b>PI Reference (Setpoint) Source Select</b>	0	1	0	-
	Selects the source for the PID Reference / Setpoint				
	<b>Setting</b>	<b>Function</b>	<b>Description</b>		
	0	Digital Preset Setpoint	P-45 is used		
	1	Analog Input 1 Setpoint	Analog input 1 signal level, readable in P00-01 is used for the setpoint.		
P-45	<b>PI Digital Setpoint</b>	0.0	100.0	0.0	%
	When P-44 = 0, this parameter sets the preset digital reference (setpoint) used for the PI Controller as a % of the feedback signal range.				
P-46	<b>PI Feedback Source Select</b>	0	5	0	-
	Selects the source of the feedback signal to be used by the PI controller.				
	<b>Setting</b>	<b>Function</b>	<b>Description</b>		
	0	Analog Input 2	(Terminal 4) Signal level readable in P00-02.		
	1	Analog Input 1	(Terminal 6) Signal level readable in P00-01		
	2	Motor Current	Scaled as % of P-08		
	3	DC Bus Voltage	Scaled 0 – 1000 Volts = 0 – 100%		
4	Analog 1 – Analog 2	The value of Analog Input 2 is subtracted from Analog 1 to give a differential signal. The value is limited to 0.			
5	Largest (Analog 1, Analog 2)	The larger of the two analog input values is always used for PI feedback.			
P-47	<b>Analog Input 2 Signal Format</b>	-	-	-	U0-10
	<b>Setting</b>	<b>Signal Type</b>	<b>Additional Information</b>		
	U 0-10	0 to 10			
	R 0-20	0 to 20mA			
	t 4-20	4 to 20mA	The drive will trip and show the fault code <b>4-20F</b> if the signal level falls below 3mA		
	r 4-20	4 to 20mA	The drive will ramp to stop if the signal level falls below 3mA		
	t 20-4	20 to 4mA	The drive will trip and show the fault code <b>4-20F</b> if the signal level falls below 3mA		
	r 20-4	20 to 4mA	The drive will ramp to stop if the signal level falls below 3mA		
Ptc-th	Motor PTC (Thermistor)	Valid with any setting of P-15 that has Input 3 as E-Trip.			
P-48	<b>Standby Mode Timer</b>	0.0	25.0	0.0	s
	When standby mode is enabled by setting P-48 > 0.0, the drive will enter standby following a period of operating at minimum speed (P-02) for the time set in P-48. When in Standby Mode, the drive display shows <b>Standby</b> , and the output to the motor is disabled.				
P-49	<b>PI Control Wake Up Error Level</b>	0.0	100.0	0.0	%
	When the drive is operating in PI Control Mode (P-12 = 5 or 6), and Standby Mode is enabled (P-48 > 0.0), P-49 can be used to define the PI Error Level (E.g. difference between the setpoint and feedback) required before the drive restarts after entering Standby Mode. This allows the drive to ignore small feedback errors and remain in Standby mode until the feedback drops sufficiently.				
P-50	<b>User Output Relay Hysteresis</b>	0.0	10.0	5.0	%
	Sets the hysteresis level for P-19 to prevent the output relay chattering when close to the threshold.				

## 1.3.3. Advanced Parameters

Par.	Description	Minimum	Maximum	Default	Units
P-51	<b>Motor Control Mode</b>	0	5	0	-
	<b>Setting</b>	<b>Control Method</b>			
	0	Vector speed control mode for Induction Motors			
	1	V/f mode for Induction Motors			
	2	PM vector speed control for Permanent Magnet Motors			
	3	BLDC vector speed control for Brushless DC Motors			
P-52	<b>Motor Parameter Autotune</b>	0	1	0	-
	This parameter can be used to optimise the performance when P-51 = 0. Autotune is not required if P-51 = 1. For settings 2 – 5 of P-51, autotune <b>MUST</b> be carried out <b>AFTER</b> all other required motor settings are entered.				
	<b>Setting</b>	<b>Function</b>	<b>Description</b>		
	0	Disabled			
1	Enabled	When enabled, the drive immediately measures required data from the motor for optimal operation. Ensure all motor related parameters are correctly set first before enabling this parameter.			
P-53	<b>Vector Mode Gain</b>	0.1	200.0	50.0	%
	Single Parameter for Vector speed loop tuning. Affects P & I terms simultaneously. Not active when P-51 = 1.				
P-54	<b>Maximum Current Limit</b>	0.1	175.0	150.0	%
Defines the max current limit in vector control modes					
P-55	<b>Motor Stator Resistance</b>	0.0	655.35	-	Ω
Motor stator resistance in Ohms. Determined by Autotune, adjustment is not normally required.					
P-56	<b>Motor Stator d-axis Inductance (Lsd)</b>	0	6553.5	-	mH
Determined by Autotune, adjustment is not normally required.					
P-57	<b>Motor Stator q-axis Inductance (Lsq)</b>	0	6553.5	-	mH
Determined by Autotune, adjustment is not normally required.					
P-58	<b>DC Injection Speed</b>	0.0	P-01	0.0	Hz / RPM
Sets the speed at which DC injection current is applied during braking to Stop, allowing DC to be injected before the drive reaches zero speed if desired.					
P-59	<b>DC Injection Current</b>	0.0	100.0	20.0	%
Sets the level of DC injection braking current applied according to the conditions set in P-32 and P-58.					
P-60	<b>Thermal Overload Retention</b>	0	1	0	-
	<b>Setting</b>	<b>Function</b>	<b>Description</b>		
	0	Disabled			
1	Enabled	When enabled, the drive calculated motor overload protection information is retained after the mains power is removed from the drive.			

## 1.4. Alternative Parameter Functions for Single Phase Output Drives

Single phase output drives feature a number of changes in order to provide optimal operation with single phase motors. These changes are based around two key principles:-

- The Starting method for single phase motors requires the motor to be started at full speed in order to provide optimal starting torque. The starting boost parameters allow adjustment of this function to provide optimal motor starting.
- It is not possible to have reverse operation with a single phase motors, thereby all reverse functions are disabled in the drive firmware.

### 1.4.1. Single Phase Output Drives – Alternative Parameters

Par.	Description	Minimum	Maximum	Default	Units
P-05	<b>Stopping Mode / Mains Loss Response</b>	0	2	0	-
	Selects the stopping mode of the drive, and the behaviour in response to a loss of mains power supply during operation.				
	<b>Setting</b>	<b>On Disable</b>	<b>On Mains Loss</b>		
	0	Ramp to Stop (P-04)	Ride Through (Recover energy from load to maintain operation)		
	1	Coast	Coast		
	2	Ramp to Stop (P-04)	Fast Ramp to Stop (P-24), Coast if P-24 = 0		
	AC Flux braking is not possible with single phase motors.				
P-06	<b>Reserved</b>	-	-	-	-
	Energy optimiser feature is not suitable for Single Phase motors				
P-11	<b>Start Boost Voltage</b>	0.0	100.0	3.0	%
	This parameter sets the initial voltage applied to the motor following a start command. The inverter applied the voltage set in this parameter at the frequency set in P-32 initially, and then ramps to the motor rated voltage set in P-09 over the time period set in P-33. Excessive voltage boost levels may result in increased motor current and temperature, and can result in the drive tripping during starting.				
P-13	<b>Reserved</b>	-	-	-	-
	Application Macro selection is not supported on single phase output drives.				
P-15	<b>Digital Input Function Select</b>	0	17	0	-
	This parameter has the same function as three phase output drives, however note that for single phase output drives, all reverse functions are disabled, and the inputs assigned have no function.				
P-20	<b>Preset Frequency / Speed 1</b>	0.0	P-01	5.0	Hz / RPM
P-21	<b>Preset Frequency / Speed 2</b>	0.0	P-01	25.0	Hz / RPM
P-22	<b>Preset Frequency / Speed 3</b>	0.0	P-01	40.0	Hz / RPM
P-23	<b>Preset Frequency / Speed 4</b>	0.0	P-01	P-09	Hz / RPM
	These parameters have alternative default settings compared to three phase drives, and are uni-directional only.				
P-32	<b>Starting Boost Frequency</b>	0.0	P-09	P-09	Hz
	Sets the frequency used during the starting boost phase of operation.				
P-33	<b>Boost Period Duration</b>	0.0	150	5.0	s
	Time for which the start-up boost period is applied. During this period, the output frequency is set to P-32 and the voltage increases linearly from P-11 to P-07. Setting P-33 to zero disables boost.				
P-51 To P-59	<b>Reserved</b>	-	-	-	-
	These parameters are not present in single phase output drives.				

## 1.5. Parameter Group 0 – Monitoring Parameters (Read Only)

Par.	Description	Explanation
P00-01	1 <sup>st</sup> Analog input value (%)	100% = max input voltage
P00-02	2 <sup>nd</sup> Analog input value (%)	100% = max input voltage
P00-03	Speed reference input (Hz / RPM)	Displayed in Hz if P-10 = 0, otherwise RPM
P00-04	Digital input status	Drive digital input status
P00-05	User PI output (%)	Displays value of the User PI output
P00-06	DC bus ripple (V)	Measured DC bus ripple
P00-07	Applied motor voltage (V)	Value of RMS voltage applied to motor
P00-08	DC bus voltage (V)	Internal DC bus voltage
P00-09	Heatsink temperature (°C)	Temperature of heatsink in °C
P00-10	Run time since date of manuf. (Hours)	Not affected by resetting factory default parameters
P00-11	Run time since last trip (1) (Hours)	Run-time clock stopped by drive disable (or trip), reset on next enable only if a trip occurred. Reset also on next enable after a drive power down.
P00-12	Run time since last trip (2) (Hours)	Run-time clock stopped by drive disable (or trip), reset on next enable only if a trip occurred (under-volts not considered a trip) – not reset by power down / power up cycling unless a trip occurred prior to power down
P00-13	Trip Log	Displays most recent 4 trips with time stamp
P00-14	Run time since last disable (Hours)	Run-time clock stopped on drive disable, value reset on next enable
P00-15	DC bus voltage log (V)	8 most recent values prior to trip, 256ms sample time
P00-16	Heatsink temperature log (V)	8 most recent values prior to trip, 30s sample time
P00-17	Motor current log (A)	8 most recent values prior to trip, 256ms sample time
P00-18	DC bus ripple log (V)	8 most recent values prior to trip, 22ms sample time
P00-19	Internal drive temperature log (°C)	8 most recent values prior to trip, 30 s sample time
P00-20	Internal drive temperature (°C)	Actual internal ambient temperature in °C
P00-21	CANopen process data input	Incoming process data (RX PDO1) for CANopen: PI1, PI2, PI3, PI4
P00-22	CANopen process data output	outgoing process data (TX PDO1) for CANopen: PO1, PO2, PO3, PO4
P00-23	Accumulated time with heatsink > 85°C (Hours)	Total accumulated hours and minutes of operation above heatsink temp of 85°C
P00-24	Accumulated time with drive internal temp > 80°C (Hours)	Total accumulated hours and minutes of operation with drive internal ambient above 80°C
P00-25	Estimated rotor speed (Hz)	In vector control modes, estimated rotor speed in Hz
P00-26	kWh meter / MWh meter	Total number of kWh / MWh consumed by the drive.
P00-27	Total run time of drive fans (Hours)	Time displayed in hh:mm:ss. First value displays time in hrs, press up to display mm:ss.
P00-28	Software version and checksum	Version number and checksum. "1" on LH side indicates I/O processor, "2" indicates power stage
P00-29	Drive type identifier	Drive rating, drive type and software version codes
P00-30	Drive serial number	Unique drive serial number
P00-31	Motor current Id / Iq	Displays the magnetising current (Id) and torque current (Iq). Press UP to show Iq
P00-32	Actual PWM switching frequency (kHz)	Actual switching frequency used by drive
P00-33	Critical fault counter – O-I	These parameters log the number of times specific faults or errors occur, and are useful for diagnostic purposes.
P00-34	Critical fault counter – O-Volts	
P00-35	Critical fault counter – U-Volts	
P00-36	Critical fault counter – O-temp (h/sink)	
P00-37	Critical fault counter – b O-I (chopper)	
P00-38	Critical fault counter – O-hEAt (control)	
P00-39	Modbus comms error counter	
P00-40	CANbus comms error counter	
P00-41	I/O processor comms errors	
P00-42	Power stage uC comms errors	
P00-43	Drive power up time (life time) (Hours)	Total lifetime of drive with power applied
P00-44	Phase U current offset & ref	Internal value
P00-45	Phase V current offset & ref	Internal value
P00-46	Phase W current offset & ref	Internal value
P00-47	Index 1 : Fire mode total active time Index 2 : Fire Mode Activation Count	Total activation time of Fire Mode Displays the number of times Fire Mode has been activated
P00-48	Scope channel 1 & 2	Displays signals for first scope channels 1 & 2
P00-49	Scope channel 3 & 4	Displays signals for first scope channels 3 & 4
P00-50	Bootloader and motor control	Internal value

## 1.6. Control Terminal Connections

For standard applications and operation, the basic control of the drive and functions of all drive input terminals can be configured using just two parameters, P-12 and P-15. P-12 is used to define the source of all control commands and the primary speed reference source. P-15 then allows fast selection of Analog and Digital Input functions based on a selection table.

### 1.6.1. P-12 Function

P-12 is used to select the main control source of the drive and the main speed reference according to the following table

P-12	Function	Control Source	Main Speed Reference	Notes
0	Terminal Control	Terminals	Analog Input 1	All control signals are applied to the control terminals. Functions are determined by P-15 Macro setting.
1	Keypad Control	Keypad / Terminals	Motorised Pot / Keypad	When keypad mode is selected, the default operation of the drive requires the keypad Start & Stop buttons are used to control the drive. This can be changed using P-31 to allow the drive to be started from Digital Input 1 directly.
2	Keypad Control	Keypad / Terminals	Motorised Pot / Keypad	
3	Modbus RTU	Modbus RTU	Modbus RTU	Control of the drive operation is through the Modbus RTU Interface. Acceleration and Deceleration Rates are controlled by P-03 and P-04 respectively. Digital Input 1 must be closed to allow operation.
4	Modbus RTU	Modbus RTU	Modbus RTU	Control of the drive operation is through the Modbus RTU Interface. Acceleration and Deceleration Rates are also controlled by Modbus, P-03 and P-04 are disabled. Digital Input 1 must be closed to allow operation.
5	PI Control	Terminals	PI Output	Enable / Disable control of the drive is through the drive control terminal strip. Output frequency is set by the output of the PI Controller
6	PI Control with Analog Summation	Terminals	PI Output Added to AI1	Enable / Disable control of the drive is through the drive control terminal strip. Output frequency is set by the output of the PI Controller, added to the value of analog input 1.
7	CAN Open	CAN Open	CAN	Control of the drive operation is through the CAN Open Interface. Acceleration and Deceleration Rates are controlled by P-03 and P-04 respectively. Digital Input 1 must be closed to allow operation.
8	CAN Open	CAN Open	CAN	Control of the drive operation is through the CAN Open Interface. Acceleration and Deceleration Rates are also controlled by Modbus, P-03 and P-04 are disabled. Digital Input 1 must be closed to allow operation.
9	Slave Mode	Master Drive	From Master	

### 1.6.2. Overview

Optidrive E3 uses a Macro approach to simplify the configuration of the Analog and Digital Inputs. There are two key parameters which determine the input functions and drive behaviour:-

- **P-12** – Selects the main drive control source and determines how the output frequency of the drive is primarily controlled.
- **P-15** – Assigns the Macro function to the analog and digital inputs.

Additional parameters can then be used to further adapt the settings, e.g.

- **P-16** – Used to select the format of the analog signal to be connected to analog input 1, e.g. 0 – 10 Volt, 4 – 20mA
- **P-30** – Determines whether the drive should automatically start following a power on if the Enable Input is present
- **P-31** – When Keypad Mode is selected, determines at what output frequency / speed the drive should start following the enable command, and also whether the keypad start key must be pressed or if the Enable input alone should start the drive.
- **P-47** – Used to select the format of the analog signal to be connected to analog input 2, e.g. 0 – 10 Volt, 4 – 20mA

The diagrams below provide an overview of the functions of each terminal macro function, and a simplified connection diagram for each.

### 1.6.3. Macro Function Guide

Function	Explanation
STOP	Latched Input, Open the contact to STOP the drive
RUN	Latched input, Close the contact to Start, the drive will operate as long as the input is maintained
FWD↻	Latched Input, selects the direction of motor rotation FORWARD
REV↻	Latched Input, selects the direction of motor rotation REVERSE
RUN FWD↻	Latched Input, Close to Run in the FORWARD direction, Open to STOP
RUN REV↻	Latched Input, Close to Run in the REVERSE direction, Open to STOP
ENABLE	Hardware Enable Input. In Keypad Mode, P-31 determines whether the drive immediately starts, or the keypad start key must be pressed. In other modes, this input must be present before the start command is applied via the fieldbus interface.
START↑	Normally Open, Rising Edge, Close momentarily to START the drive (NC STOP Input must be maintained)
^ START -^	Simultaneously applying both inputs momentarily will START the drive (NC STOP Input must be maintained)
STOP↓	Normally Closed, Falling Edge, Open momentarily to STOP the drive
START↑FWD↻	Normally Open, Rising Edge, Close momentarily to START the drive in the forward direction (NC STOP Input must be maintained)
START↑REV↻	Normally Open, Rising Edge, Close momentarily to START the drive in the reverse direction (NC STOP Input must be maintained)
^-FAST STOP (P-24)-^	When both inputs are momentarily active simultaneously, the drive stops using Fast Stop Ramp Time P-24
FAST STOP↓ (P-24)	Normally Closed, Falling Edge, Open momentarily to FAST STOP the drive using Fast Stop Ramp Time P-24
E-TRIP	Normally Closed, External Trip input. When the input opens momentarily, the drive trips showing $E-Err$ or $Ptc-Err$ depending on P-47 setting
Fire Mode	Activates Fire Mode, see section 1.7.1 Fire Mode
Analog Input AI1	Analog Input 1, signal format selected using P-16
Analog Input AI2	Analog Input 2, signal format selected using P-47
AI1 REF	Analog Input 1 provides the speed reference
AI2 REF	Analog Input 2 provides the speed reference
P-xx REF	Speed reference from the selected preset speed
PR-REF	Preset speeds P-20 – P-23 are used for the speed reference, selected according to other digital input status
PI-REF	PI Control Speed Reference
PI FB	Analog Input used to provide a Feedback signal to the internal PI controller
KPD REF	Keypad Speed Reference selected
INC SPD↑	Normally Open, Close the input to Increase the motor speed
DEC SPD↓	Normally Open, Close input to Decrease motor speed
FB REF	Selected speed reference from Fieldbus (Modbus RTU / CAN Open / Master depending on P-12 setting)
(NO)	Input is Normally Open, Close momentarily to activate the function
(NC)	Input is Normally Closed, Open momentarily to activate the function

1.6.4. Macro Functions – Terminal Mode (P-12 = 0)

P-15	DI1		DI2		DI3 / AI2		DI4 / AI1		Diagram	
	0	1	0	1	0	1	0	1		
0	STOP	RUN	FWD ↻	REV ↻	AI1 REF	P-20 REF	Analog Input AI1		1	
1	STOP	RUN	AI1 REF	PR-REF	P-20	P-21	Analog Input AI1		1	
2	STOP	RUN	<b>DI2</b>	<b>DI3</b>	<b>PR</b>		P-20 - P-23	P-01	2	
			0	0	P-20					
			1	0	P-21					
			0	1	P-22					
			1	1	P-23					
3	STOP	RUN	AI1 REF	P-20 REF	E-TRIP ↓	(NC)	Analog Input AI1		3	
4	STOP	RUN	AI1 REF	AI2 REF	Analog Input AI2		Analog Input AI1		4	
5	STOP	RUN FWD ↻	STOP	RUN REV ↻	AI1 REF	P-20 REF	Analog Input AI1		1	
		^-----FAST STOP (P-24)-----^								
6	STOP	RUN	FWD ↻	REV ↻	E-TRIP ↓	(NC)	Analog Input AI1		3	
7	STOP	RUN FWD ↻	STOP	RUN REV ↻	E-TRIP ↓	(NC)	Analog Input AI1		3	
		^-----FAST STOP (P-24)-----^								
8	STOP	RUN	FWD ↻	REV	<b>DI3</b>	<b>DI4</b>	<b>PR</b>		2	
					0	0	P-20			
					1	0	P-21			
					0	1	P-22			
			1	1	P-23					
9	STOP	RUN ↕ FWD ↻	STOP	RUN ↕ REV ↻	<b>DI3</b>	<b>DI4</b>	<b>PR</b>		2	
		^-----FAST STOP (P-24)-----^				0	0	P-20		
						1	0	P-21		
						0	1	P-22		
					1	1	P-23			
10	(NO)	START ↑	STOP ↓	(NC)	AI1 REF	P-20 REF	Analog Input AI1		5	
11	(NO)	START ↕ FWD ↻	STOP ↓	(NC)	(NO)	START ↕ REV ↻	Analog Input AI1		6	
		^-----FAST STOP (P-24)-----^								
12	STOP	RUN	FAST STOP ↓ (P-24)	(NC)	AI1 REF	P-20 REF	Analog Input AI1		7	
13	(NO)	START ↕ FWD ↻	STOP ↓	(NC)	(NO)	START ↕ REV ↻	KPD REF	P-20 REF	13	
		^-----FAST STOP (P-24)-----^								
14	STOP	RUN	<b>DI2</b>		E-TRIP ↓	(NC)	<b>DI2</b>	<b>DI4</b>	<b>PR</b>	11
			0	0			P-20			
			1	0			P-21			
			0	1			P-22			
			1	1	P-23					
15	STOP	RUN	P-23 REF	AI1	Fire Mode		Analog Input AI1		1	
16	STOP	RUN	P-23 REF	P-21 REF	Fire Mode		FWD ↻	REV ↻	2	
17	STOP	RUN	<b>DI2</b>		E-TRIP ↓	(NC)	<b>DI2</b>	<b>DI4</b>	<b>PR</b>	2
			0	0			P-20			
			1	0			P-21			
			0	1			P-22			
			1	1	P-23					

1.6.5. Macro Functions - Keypad Mode (P-12 = 1 or 2)

P-15	DI1		DI2		DI3 / AI2		DI4 / AI1		Diagram
	0	1	0	1	0	1	0	1	
0	STOP	ENABLE	-	INC SPD ↑	-	DEC SPD ↓	FWD ↻	REV ↻	8
				^-----START-----^					
1	STOP	ENABLE	PI REF						
2	STOP	ENABLE	-	INC SPD ↑	-	DEC SPD ↓	KPD REF	P-20 REF	8
				^-----START-----^					
3	STOP	ENABLE	-	INC SPD ↑	E-TRIP ↓	(NC)	-	DEC SPD ↓	9
				^-----START-----^					
4	STOP	ENABLE	-	INC SPD ↑	KPD REF	AI1 REF	Analog Input AI1		10
5	STOP	ENABLE	FWD ↻	REV ↻	KPD REF	AI1 REF	Analog Input AI1		1
6	STOP	ENABLE	FWD ↻	REV ↻	E-TRIP ↓	(NC)	KPD REF	P-20 REF	11
7	STOP	RUN FWD ↻	STOP	RUN REV ↻	E-TRIP ↓	(NC)	KPD REF	P-20 REF	11
		^-----FAST STOP (P-24)-----^							
14	STOP	RUN	-	-	E-TRIP ↓	(NC)	-	-	
15	STOP	RUN	PR REF	KPD REF	Fire Mode		P-23	P-21	2
16	STOP	RUN	P-23 REF	KPD REF	Fire Mode		FWD ↻	REV ↻	2
17	STOP	RUN	KPD REF	P-23 REF	Fire Mode		FWD ↻	REV ↻	2

8,9,10,11,12, 13 = 0




**1.6.6. Macro Functions - Fieldbus Control Mode (P-12 = 3, 4, 7, 8 or 9)**

P-15	DI1		DI2		DI3 / AI2		DI4 / AI1		Diagram
	0	1	0	1	0	1	0	1	
0	STOP	ENABLE	FB REF (Fieldbus Speed Reference, Modbus RTU / CAN / Master-Slave defined by P-12)						14
1	STOP	ENABLE	PI REF						15
3	STOP	ENABLE	FB REF	P-20 REF	E-TRIP ↓	(NC)	Analog Input AI1		3
5	STOP	ENABLE	FB REF	PR REF	P-20	P-21	Analog Input AI1		1
6	STOP	ENABLE	FB REF	AI1 REF	E-TRIP ↓	(NC)	Analog Input AI1		3
7	STOP	ENABLE	FB REF	KPD REF	E-TRIP ↓	(NC)	Analog Input AI1		3
14	STOP	ENABLE	-	-	E-TRIP ↓	(NC)	Analog Input AI1		16
15	STOP	ENABLE	PR REF	FB REF	Fire Mode		P-23	P-21	2
16	STOP	ENABLE	P-23 REF	FB REF	Fire Mode		Analog Input AI1		1
17	STOP	ENABLE	FB REF	P-23 REF	Fire Mode		Analog Input AI1		1
<b>2,4,8,9,10,11,12,13 = 0</b>									

**1.6.7. Macro Functions - User PI Control Mode (P-12 = 5 or 6)**

P-15	DI1		DI2		DI3 / AI2		DI4 / AI1		Diagram
	0	1	0	1	0	1	0	1	
0	STOP	ENABLE	PI REF	P-20 REF	Analog Input AI2		Analog Input AI1		4
1	STOP	ENABLE	PI REF	AI1 REF	Analog Input AI2 (PI FB)		Analog Input AI1		4
3, 7	STOP	ENABLE	PI REF	P-20	E-TRIP ↓	(NC)	Analog Input AI1 (PI FB)		3
4	(NO)	START ↑	(NC)	STOP ↓	Analog Input AI2 (PI FB)		Analog Input AI1		12
5	(NO)	START ↑	(NC)	STOP ↓	PI REF	P-20 REF	Analog Input AI1 (PI FB)		5
6	(NO)	START ↑	(NC)	STOP ↓	E-TRIP ↓	(NC)	Analog Input AI1 (PI FB)		
8	STOP	RUN	FWD ↻	REV ↻	Analog Input AI2 (PI FB)		Analog Input AI1		4
14	STOP	RUN	-	-	E-TRIP ↓	(NC)	Analog Input AI1 (PI FB)		16
15	STOP	RUN	P-23 REF	PI REF	Fire Mode		Analog Input AI1 (PI FB)		1
16	STOP	RUN	P-23 REF	P-21 REF	Fire Mode		Analog Input AI1 (PI FB)		1
17	STOP	RUN	P-21 REF	P-23 REF	Fire Mode		Analog Input AI1 (PI FB)		1
<b>2,9,10,11,12,13 = 0</b>									

1.6.8. Example Connection Diagrams



## 1.7. Software Functions

### 1.7.1. Fire Mode

The Fire Mode function is designed to ensure continuous operation of the drive in emergency conditions until the drive is no longer capable of sustaining operation. The Fire Mode input may be a normally open (Close to Activate Fire Mode) or Normally Closed (Open to Activate Fire Mode) according to the setting of P-30 Index 2. In addition, the input may be momentary or maintained type, selected by P-30 Index 3. This input may be linked to a fire control system to allow maintained operation in emergency conditions, e.g. to clear smoke or maintain air quality within that building.

The fire mode function is enabled when P-15 = 15, 16 or 17, with Digital Input 3 assigned to activate fire mode.

Fire Mode disables the following protection features in the drive:-

- O-t Heat-sink Over-Temperature
- U-t Drive Under Temperature
- Th-FLt Faulty Thermistor on Heat-sink
- E-trip External Trip
- 4-20 F 4-20mA fault
- Ph-Ib Phase Imbalance
- P-Loss Input Phase Loss Trip
- SC-trp Communications Loss Trip
- It-trp Accumulated overload Trip
- Out-F Drive output fault, Output stage trip

The following faults will result in a drive trip, auto reset and restart:-

- O-Volt Over Voltage on DC Bus
- U-Volt Under Voltage on DC Bus
- h O-I Fast Over-current Trip
- O-I Instantaneous over current on drive output

## 2. Drive Model Specific Parameter Variations

### 2.1. Available Effective Switching Frequency Options

110 Volt, 1 Phase Models (Voltage Doubler)					
Frame	kW	HP	Default	Minimum	Maximum
1	0.37	0.5	8 kHz	4 kHz	32 kHz
1	0.75	1	8 kHz	4 kHz	32 kHz
2	1.1	1.5	8 kHz	4 kHz	32 kHz
230 Volt, 1 Phase Models					
Frame	kW	HP	Default	Minimum	Maximum
1	0.37	0.5	8 kHz	4 kHz	32 kHz
1	0.75	1	8 kHz	4 kHz	32 kHz
1	1.5	2	8 kHz	4 kHz	32 kHz
2	1.5	2	8 kHz	4 kHz	32 kHz
2	2.2	3	8 kHz	4 kHz	32 kHz
3	4	5	8 kHz	4 kHz	24 kHz
230 Volt, 3 Phase Models					
Frame	kW	HP	Default	Minimum	Maximum
1	0.37	0.5	8 kHz	4 kHz	32kHz
1	0.75	1	8 kHz	4 kHz	32 kHz
1	1.5	2	8 kHz	4 kHz	32 kHz
2	1.5	2	8 kHz	4 kHz	32 kHz
2	2.2	3	8 kHz	4 kHz	32 kHz
3	3	4	8 kHz	4 kHz	24 kHz
3	4	5	8 kHz	4 kHz	24 kHz
4	5.5	7.5	8 kHz	4 kHz	24 kHz
4	7.5	10	8 kHz	4 kHz	24 kHz
4	11	15	8 kHz	4 kHz	24 kHz
400 Volt, 3 Phase Models					
Frame	kW	HP	Default	Minimum	Maximum
1	0.75	1	8 kHz	4 kHz	32 kHz
1	1.5	2	8 kHz	4 kHz	32 kHz
2	1.5	2	8 kHz	4 kHz	32 kHz
2	2.2	3	8 kHz	4 kHz	32 kHz
2	4	5	8 kHz	4 kHz	32 kHz
3	5.5	7.5	8 kHz	4 kHz	24 kHz
3	7.5	10	8 kHz	4 kHz	24 kHz
3	11	15	8 kHz	4 kHz	24 kHz
4	15	20	8 kHz	4 kHz	24 kHz
4	18.5	25	8 kHz	4 kHz	24 kHz
4	22	30	8 kHz	4 kHz	24 kHz

## 2.2. V/F Mode Voltage Boost Setting Options

110 Volt, 1 Phase Input Models (Voltage Doubler)				
Frame	kW	HP	Default	Maximum
1	0.37	0.5	3.0%	25.0%
1	0.75	1	3.0%	25.0%
2	1.1	1.5	2.5%	20.0%
230 Volt, 1 Phase Input Models				
Frame	kW	HP	Default	Maximum
1	0.37	0.5	3.0%	25.0%
1	0.75	1	3.0%	25.0%
1	1.5	2	3.0%	25.0%
2	1.5	2	2.5%	20.0%
2	2.2	3	2.5%	20.0%
3	4	5	2.0%	15.0%
230 Volt, 3 Phase Input Models				
Frame	kW	HP	Default	Maximum
1	0.37	0.5	3.0%	25.0%
1	0.75	1	3.0%	25.0%
1	1.5	2	3.0%	25.0%
2	1.5	2	2.5%	20.0%
2	2.2	3	2.5%	20.0%
3	3	4	2.0%	15.0%
3	4	5	2.0%	15.0%
4	5.5	7.5	1.5%	10.0%
4	7.5	10	1.5%	10.0%
4	11	15	1.5%	10.0%
400 Volt 3 Phase Input Models				
Frame	kW	HP	Default	Maximum
1	0.75	1	3.0%	25.0%
1	1.5	2	3.0%	25.0%
2	1.5	2	2.5%	20.0%
2	2.2	3	2.5%	20.0%
2	4	5	2.5%	20.0%
3	5.5	7.5	2.0%	15.0%
3	7.5	10	2.0%	15.0%
3	11	15	2.0%	15.0%
4	15	20	1.5%	10.0%
4	18.5	25	1.5%	10.0%
4	22	30	1.5%	10.0%

## 3. Fieldbus Interface Support

### 3.1. Fieldbus Support Overview

Optidrive E3 provides support for the following fieldbus networks and functions

Fieldbus	Interface	Availability	Drive Control	Drive Parameter Access
Modbus RTU	On-board RJ45	From Launch	Yes	Access to all Writable Parameters
CAN bus	On-board RJ45	From Launch	Yes	Access to all Writable Parameters

### 3.2. Modbus RTU

Optidrive E3 supports Modbus RTU communication, using the 03 Read Holding Registers and 06 Write Single Holding Register commands. Many Master devices treat the first Register address as Register 0; therefore it may be necessary to convert the register numbers listed below by subtracting 1 to obtain the correct Register address. The telegram structure is as follows:-

Command 03 – Read Holding Registers				
Master Telegram	Length		Slave Response	Length
Slave Address	1	Byte	Slave Address	1 Byte
Function Code (03)	1	Byte	Starting Address	1 Byte
1 <sup>st</sup> Register Address	2	Bytes	1 <sup>st</sup> Register Value	2 Bytes
No. Of Registers	2	Bytes	2 <sup>nd</sup> Register Value	2 Bytes
CRC Checksum	2	Bytes	Etc...	
			CRC Checksum	2 Bytes

Command 06 – Write Single Holding Register				
Master Telegram	Length		Slave Response	Length
Slave Address	1	Byte	Slave Address	1 Byte
Function Code (06)	1	Byte	Function Code (06)	1 Byte
Register Address	2	Bytes	Register Address	2 Bytes
Value	2	Bytes	Register Value	2 Bytes
CRC Checksum	2	Bytes	CRC Checksum	2 Bytes

The table shows the Modbus RTU register number corresponding to each parameter value. All values are holding registers. All User Adjustable parameters are accessible by Modbus, except those that would directly affect the Modbus communications, e.g.

- P-36 Index 1 Drive Fieldbus Address
- P-36 Index 2 Baud Rate
- P-36 Index 3 Comms Loss Timeout

All parameter values can be read from the drive and written to, depending on the operating mode of the drive – some parameters cannot be changed whilst the drive is enabled for example.

### 3.3. CAN Open

The CANopen communication profile in the Optidrive E3 is implemented according to the specification DS301 version 4.02 of CAN in automation ([www.can-cia.de](http://www.can-cia.de)). Specific device profiles such as DS402 are not supported.

The CANopen communication function is enabled by default after power up. However in order to use any control functions through CANopen, this requires P-12 = 7 or 8.

The CAN communication baud rate can be set by using parameter P-36. Available baud rates are: 125kbps, 250kbps, 500kbps, 1Mbps. (with default settings as 500kbps).

The Node ID is set up through drive address parameter P-36 as well with the default value of 1.

The tables below show the Index and Sub Index required to address each parameter. All User Adjustable parameters are accessible by CAN, except those that would directly affect the communications.

All parameter values can be read from the drive and written to, depending on the operating mode of the drive – some parameters may be changed whilst the drive is enabled for example.

Optidrive E3 provides the following default COB-ID and functions:

Type	COB-ID	Function
NMT	000h	Network management
Sync	080h	Synchronous message COB-ID can be configured to other value.
Emergency	080h + Node address	Emergency message
PDO1 (TX)	180h + Node address	Process data object. PDO1 is pre-mapped and enabled by default. COB-ID can be configured to other value. PDO2 is pre-mapped and disabled by default. Transmission mode, COB-ID and mapping can be configured.
PDO1 (RX)	200h + Node address	
PDO2 (TX)	280h + Node address	
PDO2 (RX)	300h + Node address	
SDO (TX)	580h + Node address	SDO channel can be used for drive parameter access.
SDO (RX)	600h + Node address	
Error Control	700h + Node address	Guarding and Heartbeat function are supported. COB-ID can be configured to other value.

#### Note

- The Optidrive E3 SDO channel only supports expedited transmission.
- The Optidrive E3 can only support up to 2 Process Data Objects (PDO). All PDOs are pre-mapped; however PDO2 is disabled by default. The table below gives the default PDO mapping information.
- Customer configuration (mapping) will NOT be saved during power down. This means that the CANopen configuration will restore to its default condition each time the drive is powered up.

**3.3.1. PDO Default Mapping**

	Objects No.	Mapped Object	Length	Mapped Function	TransmissionType
RX PDO1	1	2000h	Unsigned 16	Control command register*	254 Valid immediately
	2	2001h	Integer 16	Speed reference	
	3	2003h	Unsigned 16	User ramp reference	
	4	0006h	Unsigned 16	Dummy	
TX PDO1	1	200Ah	Unsigned 16	Drive status register	254 Send after receiving RX PDO 1
	2	200Bh	Integer 16	Motor speed Hz	
	3	200Dh	Unsigned 16	Motor current	
	4	2010h	Integer 16	Drive temperature	
RX PDO2	1	0006h	Unsigned 16	Dummy	254
	2	0006h	Unsigned 16	Dummy	
	3	0006h	Unsigned 16	Dummy	
	4	0006h	Unsigned 16	Dummy	
TX PDO2	1	2011h	Unsigned 16	DC bus voltage	254
	2	2012h	Unsigned 16	Digital input status	
	3	2013h	Integer 16	Analog input 1 (%)	
	4	2014h	Integer 16	Analog input 2 (%)	

\* Drive control can only be achieved when P-12=7 or 8 provided that P-31 = 0, 1, 4 or 5.

**3.3.2. PDO transmission type**

Various transmission modes can be selected for each PDO. For RX PDO, the following modes are supported:-

Transmission Type	Mode	Description
0 – 240	Synchronous	The received data will be transferred to the drive active control register when the next sync message is received.
254, 255	Asynchronous	The received data will be transferred to the drive active control register immediately without delay.

For TX PDO, the following modes are supported:-

Transmission Type	Mode	Description
0	Acyclic synchronous	TX PDO will only be sent out if the PDO data has changed and PDO will be transmitted on reception of SYNC object
1-240	Cyclic synchronous	TX PDO will be transmitted synchronously and cyclically. The transmission type indicates the number of SYNC object that are
254	Asynchronous	TX PDO will only be transferred once corresponding RX PDO has been received.
255	Asynchronous	TX PDO will only be transferred anytime if PDO data value has changed.

## 3.3.3. CAN Open Specific Object Table

Index	Sub Index	Function	Access	Type	PDO Map	Default Value
1000h	0	Device Type	R	U32	N	0
1001h	0	Error Register	R	U8	N	0
1002h	0	Manufacturer Status Register	R	U16	N	0
1005h	0	COB-ID Sync	RW	U32	N	00000080h
1008h	0	Manufacturer Device Name	R	String	N	ODE3
1009h	0	Manufacturer Hardware Version	R	String	N	x.xx
100Ah	0	Manufacturer Software Version	R	String	N	x.xx
100Ch	0	Guard Time (1ms)	RW	U16	N	0
100Dh	0	Life Time Factor	RW	U8	N	0
1014h	0	COB-ID EMCY	RW	U32	N	00000080h+Node ID
1015h	0	Inhibit Time Emergency (100µs)	RW	U16	N	0
1017h	0	Producer Heartbeat Time (1ms)	RW	U16	N	0
1018h	0	Identity Object No. Of entries	R	U8	N	4
	1	Vendor ID	R	U32	N	0x0000031A
	2	Product Code	R	U32	N	Drive Dependent
	3	Revision Number	R	U32	N	x.xx
	4	Serial Number	R	U32	N	Drive Dependent
1200h	0	SDO Parameter No. Of entries	R	U8	N	2
	1	COB-ID Client -> Server (RX)	R	U32	N	00000600h+Node ID
	2	COB-ID Server -> Client (TX)	R	U32	N	00000580h+Node ID
1400h	0	RX PDO1 comms param. no. of entries	R	U8	N	2
	1	RX PDO1 COB-ID	RW	U32	N	40000200h+Node ID
	2	RX PDO1 transmission type	RW	U32	N	254
1401h	0	RX PDO2 comms param. no. of entries	R	U8	N	2
	1	RX PDO2 COB-ID	RW	U32	N	C0000300h+Node ID
	2	RX PDO2 transmission type	RW	U8	N	0
1600h	0	RX PDO1 1 mapping / no. of entries	RW	U8	N	4
	1	RX PDO1 1st mapped object	RW	U32	N	20000010h
	2	RX PDO1 2nd mapped object	RW	U32	N	20010010h
	3	RX PDO1 3rd mapped object	RW	U32	N	20030010h
	4	RX PDO1 4th mapped object	RW	U32	N	00060010h
1601h	0	RX PDO2 1 mapping / no. of entries	RW	U8	N	4
	1	RX PDO2 1st mapped object	RW	U32	N	00060010h
	2	RX PDO2 2nd mapped object	RW	U32	N	00060010h
	3	RX PDO2 3rd mapped object	RW	U32	N	00060010h
	4	RX PDO2 4th mapped object	RW	U32	N	00060010h
1800h	0	TX PDO1 comms parameter number of entries	R	U8	N	3
	1	TX PDO1 COB-ID	RW	U32	N	40000180h+Node ID
	2	TX PDO1 transmission type	RW	U8	N	254
	3	TX PDO1 Inhibit time (100µs)	RW	U16	N	0
1801h	0	TX PDO2 comms param no. of entries	R	U8	N	3
	1	TX PDO2 COB-ID	RW	U32	N	C0000280h+Node ID
	2	TX PDO2 transmission type	RW	U8	N	0
	3	TX PDO2 Inhibit time (100µs)	RW	U16	N	0
1A00h	0	TX PDO1 mapping / no. of entries	RW	U8	N	4
	1	TX PDO1 1st mapped object	RW	U32	N	200A0010h
	2	TX PDO1 2nd mapped object	RW	U32	N	200B0010h
	3	TX PDO1 3rd mapped object	RW	U32	N	200D0010h
	4	TX PDO1 4th mapped object	RW	U32	N	20100010h
1A01h	0	TX PDO2 mapping / no. of entries	RW	U8	N	4
	1	TX PDO2 1st mapped object	RW	U32	N	20110010h
	2	TX PDO2 2nd mapped object	RW	U32	N	20120010h
	3	TX PDO2 3rd mapped object	RW	U32	N	20130010h
	4	TX PDO2 4th mapped object	RW	U32	N	20140010h



### 3.4. Parameter Access Overview

The accessible parameter numbers and respective scaling are listed in the following tables. The method to access the parameters depends on the fieldbus type in use as described in the following section.

The R/W column indicates whether the values are Writeable as well as readable (R/W) or Read Only (R)

The data types for the parameter are defined as follows:-

- WORD Hexadecimal Word
- U16 Unsigned 16 Bit Value
- S16 Signed 16 Bit Value

#### 3.4.1. Modbus RTU Register / CAN Open Index Data – Control & Monitoring

Modbus RTU Register	CAN Open Index	Sub Index	PDO Map	Parameter Number	Upper byte	Lower Byte	Format	Min	Max	Type	Scaling
1	2000h	0	Y	-	Control Word		WORD	-	-	R/W	See Below
2	2001h	0	Y	-	Frequency Setpoint		S16	-5000	5000	R/W	1dp, e.g. 100 = 10.0Hz
3	2002h	0	Y	-	Reserved		-	-	-	R/W	No function
4	2003h	0	Y	-	Modbus ramp control time		U16	0	60000	R/W	2dp, e.g. 500 = 5.00s
5	2004h	0	Y	-	High Resolution Frequency Setpoint		S16	-30000	30000	R	See Below
6	200Ah	0	Y	-	Error code	Drive status	WORD	-	-	R	See Below
7	200Bh	0	Y	-	Output Frequency		S16	0	5000	R	1dp, e.g. 100 = 10.0Hz
8	200Dh	0	Y	-	Motor Current		U16	0	-	R	1dp, e.g. 100 = 10.0A
9	200Eh	0	Y	-	Motor Torque		S16	0	2000	R	1dp, e.g. 100 = 10.0%
10	200Fh	0	Y	-	Motor Power		U16	0	-	R	2dp, e.g. 100 = 1.00kW
11	2012h	0	Y	P00-04	Digital Input Status		WORD	-	-	R	See Below
12	-	-	-	P00-20	Rating ID		U16	-	-	R	Internal Value
13	-	-	-	P00-20	Power rating		U16	-	-	R	2dp, e.g. 37 = 0.37kW / HP
14	-	-	-	P00-20	Voltage rating		U16	-	-	R	See Below
15	27E8h	0	N	P00-18	IO processor software version		U16	-	-	R	2dp, e.g. 300 = 3.00
16	27EAh	0	N	P00-18	Motor control processor software version		U16	-	-	R	2dp, e.g. 300 = 3.00
17	-	-	-	P00-20	Drive type		U16	-	-	R	Internal Value
18	201Ch	0	Y	P00-48	Scope Channel 1 Data		S16	-	-	R	Internal Format
19	201Dh	0	Y	P00-48	Scope Channel 2 Data		S16	-	-	R	Internal Format
-	201Eh	0	Y	P00-49	Scope Channel 3 Data		S16	-	-	R	Internal Format
-	201Fh	0	Y	P00-49	Scope Channel 4 Data		S16	-	-	R	Internal Format
20	2013h	0	Y	P00-01	Analog 1 input result		U16	0	1000	R	1dp, e.g. 500 = 50.0%
21	2014h	0	Y	P00-02	Analog 2 input result		U16	0	1000	R	1dp, e.g. 500 = 50.0%
-	2015h	0	Y	-	Analog Output %		U16	0	1000	R	1dp, e.g. 500 = 50.0%
22	-	-	-	P00-03	Pre Ramp Speed Reference Value		S16	0	5000	R	1dp, e.g. 500 = 50.0Hz
23	2011h	0	Y	P00-08	DC Bus Voltage		U16	0	1000	R	600 = 600 Volts
24	-	-	-	P00-09	Drive Power Stage Temperature		S16	-10	150	R	50 = 50°C
-	2043h	0	Y	-	Control board temperature		S16	-10	150	R	50 = 50°C
25	-	-	-	P00-30	Drive Serial Number 4		U16	-	-	R	See Below
26	-	-	-	P00-30	Drive Serial Number 3		U16	-	-	R	
27	-	-	-	P00-30	Drive Serial Number 2		U16	-	-	R	
28	-	-	-	P00-30	Drive Serial Number 1		U16	-	-	R	
29	2017h	0	Y	-	Relay Output Status		WORD	0	1	R	Bit 0 Indicates Relay Status 1 = Relay Contacts Closed
30	-	-	-	-	Reserved		-	-	-	R	No Function
31	-	-	-	-	Reserved		-	-	-	R	No Function
32	203Ch	0	Y	P00-26	kWh Meter		U16	0	9999	R	1dp, e.g. 100 = 10.0kWh
33	203Dh	0	Y	P00-26	MWh Meter		U16	0	-	R	10 = 10MWh
34	203Eh	0	Y	P00-10	Running Time – Hours		U16	-	-	R	1 = 1 Hour
35	203Fh	0	Y	P00-10	Running Time – Minutes & Seconds		U16	-	-	R	100 = 100 Seconds
36	2040h	0	Y	P00-14	Run time since last enable – Hours		U16	-	-	R	1 = 1 Hour
37	2041h	0	Y	P00-14	Run time since last enable – Minutes & seconds		U16	-	-	R	100 = 100 Seconds
38	-	-	-	-	Reserved		U16	-	-	R	No Function
39	2010h	0	Y	P00-20	Internal Drive Temperature		S16	-10	100	R	20 = 20C
40	2044h	0	Y	-	Speed Reference (Internal Format)		U16	0	P-01	R	3000 = 50Hz
41	-	-	-	-	Reserved		-	-	-	R	No Function
42	2046h	0	Y	-	Digital Pot / Keypad Reference		U16	0	P-01	R	3000 = 50Hz
43	2048h	0	Y	P00-07	Output Voltage		U16	0	-	R	100 = 100 Volts AC RMS
44	-	-	-	-	Parameter Access Index		U16	1	60	R	See Below
45	-	-	-	-	Parameter Access Value		S16	-	-	R	See Below
-	2049h	0	Y	P00-05	PI Output		U16	0	1000	R	1000 = 100.0%
-	23E8h	0	N	-	Scope Index 12		-	-	-	RW	
-	23E9h	0	N	-	Scope Index 34		-	-	-	RW	
-	27D0h	0	N	P00-11	Run Time Since Last Trip 1 – Hours		U16	0	65535	R	1 = 1 Hour
-	27D1h	0	N	P00-11	Run Time Since Last Trip 1 - Seconds		U16	0	3599	R	100 = 100 Seconds
-	27D2h	0	N	P00-12	Run Time Since Last Trip 2 – Hours		U16	0	65535	R	1 = 1 Hour
-	27D3h	0	N	P00-12	Run Time Since Last Trip 2 - Seconds		U16	0	3599	R	100 = 100 Seconds
-	27D4h	0	N	P00-13	Trip Log 2 & 1		WORD	-	-	R	
-	27D5h	0	N	P00-13	Trip Log 4 & 3		WORD	-	-	R	

Modbus RTU Register	CAN Open Index	Sub Index	PDO Map	Parameter Number	Upper byte	Lower Byte	Format	Min	Max	Type	Scaling
-	27D6h	0	N	P00-13	Trip 1 Time – Hours		U16	0	65535	R	1 = 1 Hour
-	26D7h	0	N	P00-13	Trip 1 Time - Seconds		U16	0	3599	R	100 = 100 Seconds
-	27D8h	0	N	P00-13	Trip 2 Time – Hours		U16	0	65535	R	1 = 1 Hour
-	27D9h	0	N	P00-13	Trip 2 Time - Seconds		U16	0	3599	R	100 = 100 Seconds
-	27DAh	0	N	P00-13	Trip 3 Time – Hours		U16	0	65535	R	1 = 1 Hour
-	27DBh	0	N	P00-13	Trip 3 Time - Seconds		U16	0	3599	R	100 = 100 Seconds
-	27DCh	0	N	P00-13	Trip 4 Time – Hours		U16	0	65535	R	1 = 1 Hour
-	27DDh	0	N	P00-13	Trip 4 Time - Seconds		U16	0	3599	R	100 = 100 Seconds
-	27DEh	0	N	P00-23	Time Heatsink > 85°C – Hours		U16	0	65535	R	1 = 1 Hour
-	27DFh	0	N	P00-23	Time Heatsink > 85°C - Seconds		U16	0	3599	R	100 = 100 Seconds
-	27E0h	0	N	P00-24	Time Internal > 80°C – Hours		U16	0	65535	R	1 = 1 Hour
-	27E1h	0	N	P00-24	Time Internal > 80°C - Seconds		U16	0	3599	R	100 = 100 Seconds
-	27E2h	0	N	P00-27	Fan Run Time – Hours		U16	0	65535	R	1 = 1 Hour
-	27E3h	0	N	P00-27	Fan Run Time - Seconds		U16	0	3599	R	100 = 100 Seconds
-	27E4h	0	N	-	Fire Mode Active Time – Hours		U16	0	65535	R	1 = 1 Hour
-	27E5h	0	N	-	Fire Mode Active Time - Seconds		U16	0	3599	R	100 = 100 Seconds
-	27E6h	0	N	-	Power On Time – Hours		U16	0	65535	R	1 = 1 Hour
-	27E7h	0	N	-	Power On Time - Seconds		U16	0	3599	R	100 = 100 Seconds
-	27E9h	0	N	P00-28	IO Checksum		WORD	-	-	R	
-	27EBh	0	N	P00-28	DSP Checksum		WORD	-	-	R	
-	27ECh	0	N	P00-19	Ambient Temperature Log 1		S16	-10	150	R	50 = 50°C
-	27Edh	0	N	P00-19	Ambient Temperature Log 2		S16	-10	150	R	50 = 50°C
-	27EEh	0	N	P00-19	Ambient Temperature Log 3		S16	-10	150	R	50 = 50°C
-	27EFh	0	N	P00-19	Ambient Temperature Log 4		S16	-10	150	R	50 = 50°C
-	27F0h	0	N	P00-19	Ambient Temperature Log 5		S16	-10	150	R	50 = 50°C
-	27F1h	0	N	P00-19	Ambient Temperature Log 6		S16	-10	150	R	50 = 50°C
-	27F2h	0	N	P00-19	Ambient Temperature Log 7		S16	-10	150	R	50 = 50°C
-	27F3h	0	N	P00-19	Ambient Temperature Log 8		S16	-10	150	R	50 = 50°C
-	27F4h	0	N	P00-15	DC Bus Voltage Log 1		U16	0	1000	R	600 = 600 Volts
-	27F5h	0	N	P00-15	DC Bus Voltage Log 2		U16	0	1000	R	600 = 600 Volts
-	27F6h	0	N	P00-15	DC Bus Voltage Log 3		U16	0	1000	R	600 = 600 Volts
-	27F7h	0	N	P00-15	DC Bus Voltage Log 4		U16	0	1000	R	600 = 600 Volts
-	27F8h	0	N	P00-15	DC Bus Voltage Log 5		U16	0	1000	R	600 = 600 Volts
-	27F9h	0	N	P00-15	DC Bus Voltage Log 6		U16	0	1000	R	600 = 600 Volts
-	27FAh	0	N	P00-15	DC Bus Voltage Log 7		U16	0	1000	R	600 = 600 Volts
-	27FBh	0	N	P00-15	DC Bus Voltage Log 8		U16	0	1000	R	600 = 600 Volts
-	27FCh	0	N	P00-16	Heatsink Temperature Log 1		S16	-10	150	R	50 = 50°C
-	27FDh	0	N	P00-16	Heatsink Temperature Log 2		S16	-10	150	R	50 = 50°C
-	27FEh	0	N	P00-16	Heatsink Temperature Log 3		S16	-10	150	R	50 = 50°C
-	27FFh	0	N	P00-16	Heatsink Temperature Log 4		S16	-10	150	R	50 = 50°C
-	2800h	0	N	P00-16	Heatsink Temperature Log 5		S16	-10	150	R	50 = 50°C
-	2801h	0	N	P00-16	Heatsink Temperature Log 6		S16	-10	150	R	50 = 50°C
-	2802h	0	N	P00-16	Heatsink Temperature Log 7		S16	-10	150	R	50 = 50°C
-	2803h	0	N	P00-16	Heatsink Temperature Log 8		S16	-10	150	R	50 = 50°C
-	2804h	0	N	P00-17	Motor Current Log 1		U16	0	-	R	1dp, e.g. 100 = 10.0A
-	2805h	0	N	P00-17	Motor Current Log 2		U16	0	-	R	1dp, e.g. 100 = 10.0A
-	2806h	0	N	P00-17	Motor Current Log 3		U16	0	-	R	1dp, e.g. 100 = 10.0A
-	2807h	0	N	P00-17	Motor Current Log 4		U16	0	-	R	1dp, e.g. 100 = 10.0A
-	2808h	0	N	P00-17	Motor Current Log 5		U16	0	-	R	1dp, e.g. 100 = 10.0A
-	2809h	0	N	P00-17	Motor Current Log 6		U16	0	-	R	1dp, e.g. 100 = 10.0A
-	280Ah	0	N	P00-17	Motor Current Log 7		U16	0	-	R	1dp, e.g. 100 = 10.0A
-	280Bh	0	N	P00-17	Motor Current Log 8		U16	0	-	R	1dp, e.g. 100 = 10.0A
-	280Ch	0	N	P00-18	DC Ripple Log 1		U16	0	-	R	1 = 1 Volt
-	280Dh	0	N	P00-18	DC Ripple Log 2		U16	0	-	R	1 = 1 Volt
-	280Eh	0	N	P00-18	DC Ripple Log 3		U16	0	-	R	1 = 1 Volt
-	280Fh	0	N	P00-18	DC Ripple Log 4		U16	0	-	R	1 = 1 Volt
-	2810h	0	N	P00-18	DC Ripple Log 5		U16	0	-	R	1 = 1 Volt
-	2811h	0	N	P00-18	DC Ripple Log 6		U16	0	-	R	1 = 1 Volt
-	2812h	0	N	P00-18	DC Ripple Log 7		U16	0	-	R	1 = 1 Volt
-	2813h	0	N	P00-18	DC Ripple Log 8		U16	0	-	R	1 = 1 Volt
-	2814h	0	N	P00-25	Estimated Rotor Speed		S16	-	-	R	
-	2815h	0	N	P00-32	Actual PWM Frequency		U16	-	-	R	
-	2816h	0	N	P00-31	Motor Current iD		U16	0	-	R	
-	2817h	0	N	P00-31	Motor Current iQ		U16	0	-	R	
-	2818h	0	N	P00-33	O-I Trip Counter		U16	0	-	R	
-	2819h	0	N	P00-34	O-V Trip Counter		U16	0	-	R	
-	281Ah	0	N	P00-35	U-V Trip Counter		U16	0	-	R	
-	281Bh	0	N	P00-36	O-T Trip Counter		U16	0	-	R	
-	281Ch	0	N	P00-37	bO-I Trip Counter		U16	0	-	R	
-	281Dh	0	N	P00-38	O-Heat Trip Counter		U16	0	-	R	

## 3.4.2. Modbus RTU / CAN Open Index – Parameters

Modbus RTU Register	CAN Open Index	Par.	Description	Format	Min	Max	Data format / scaling
129	2065h	01	Max speed limit	U16	0	5*P-09	Internal value (3000 = 50.0Hz)
130	2066h	02	Min speed limit	U16	0	P-01	Internal value (3000 = 50.0Hz)
131	2067h	03	Accel ramp time	U16	0	60000	2dp, e.g. 300=3.00s
132	2068h	04	Decel ramp time	U16	0	60000	2dp, e.g. 300=3.00s
133	2069h	05	Stop Mode	U16	0	2	0: Ramp to stop + Mains Loss Ride Through 1: Coast to stop 2: Ramp to stop + Fast Stop 3 : AC Flux Braking + Fast Stop
134	206Ah	06	Energy Optimiser	U16	0	1	0: Disabled 1: Enabled
135	206Bh	07	Motor rated voltage	U16	0	250 500	400 = 400 Volts
136	206Ch	08	Motor rated current	U16	0	Drive Rating Dependent	1dp, e.g. 100 = 10.0A
137	206Dh	09	Motor rated frequency	U16	25	500	Data unit is in Hz
138	206Eh	10	Motor rated speed	U16	0	30000	Maximum value equals to the sync speed of a typical 2-pole motor
139	206Fh	11	Boost Value	U16	0	Drive Rating Dependent	1dp, e.g. 100 = 10.0%
140	2070h	12	Control mode	U16	0	6	0: Terminal Control 1: Keypad forward only 2: Keypad forward and reverse 3: Modbus control mode 4: Modbus control with ramp control 5 : PID control 6 : PID control with analog speed sum 7 : CAN Open 8 : CAN Open + Ramp Control 9 : Slave Mode
141	2071h	13	Application Mode	U16	0	2	0 : Industrial Mode 1 : Pump Mode 2 : Fan Mode
142	2072h	14	Access code	U16	0	9999	No Scaling
143	2073h	15	Digital input function	U16	0	17	See section 1.6 for function details
144	2074h	16	Analog input format	U16	0	7	0: 0...10V 1: b 0...10V 2: 0...20mA 3: t 4...20mA 4: r 4...20mA 5: t 20...4mA 6: r 20...4mA 7 : 10...0V
145	2075h	17	Effective switching frequency	U16	0	5 (Drive Rating Dependent)	0 = 4KHz 1 = 8KHz 2 = 12KHz 3 =16KHz 4 = 24KHz 5 = 32KHz
146	2076h	18	Relay Output Function	U16	0	9	See parameter description for details
147	2077h	19	Digital Threshold	U16	0	1000	100 = 10.0%
148	2078h	20	Preset Speed 1	U16	-P-01	P-01	Internal value (3000 = 50.0Hz)
149	2079h	21	Preset Speed 2	U16	-P-01	P-01	Internal value (3000 = 50.0Hz)
150	207Ah	22	Preset Speed 3	U16	-P-01	P-01	Internal value (3000 = 50.0Hz)
151	207Bh	23	Preset Speed 4	U16	-P-01	P-01	Internal value (3000 = 50.0Hz)
152	207Ch	24	2 <sup>nd</sup> Ramp	U16	0	2500	2dp e.g. 250 = 2.50s
153	207Dh	25	Analog Output Function	U16	0	10	See user guide for function details
154	207Eh	26	Skip Frequency Centre	U16	0	P-01	Internal value (3000 = 50.0Hz)
155	207Fh	27	Skip Frequency Band	U16	0	P-01	Internal value (3000 = 50.0Hz)
156	2080h	28	V/F Adjust Voltage	U16	0	P-07	100 = 100V
157	2081h	29	V/F Adjust Frequency	U16	0	P-09	50 = 50Hz
158	2082h	30	Start Mode Select	WORD	See Below		
159	2083h	31	Keypad restart mode	U16	0	7	See parameter description for details
160	2084h	32	DC Injection	WORD	See Below		
161	2085h	33	Spin Start Enable	U16	0	2	See parameter description for details
162	2086h	34	Brake circuit enable	U16	0	4	See parameter description for details
163	2087h	35	Analog Input / Slave Scaling	U16	0	20000	1000 = 100.0%
164	2088h	36	Communication Settings	WORD	See Below		
165	2089h	37	Access code definition	U16	0	9999	
166	208Ah	38	Parameter lock	U16	0	1	0: Unlocked 1: Locked
167	208Bh	39	Analog input offset	U16	-5000	5000	1dp, e.g. 300=30.0%
168	208Ch	40	Display Scaling Function	WORD	See Below		
169	208Dh	41	User PI P gain	U16	1	300	1dp, e.g. 10 = 1.0
170	208Eh	42	User PI I time constant	U16	0	300	1dp, e.g. 10 = 1.0s

Modbus RTU Register	CAN Open Index	Par.	Description	Format	Min	Max	Data format / scaling
171	208Fh	43	User PI mode select	U16	0	1	See parameter description for details
172	2090h	44	User PI reference select	U16	0	1	See parameter description for details
173	2091h	45	User PI digital reference	U16	0	1000	1dp, e.g. 100 = 10.0%
174	2092h	46	User PI feedback select	U16	0	3	See parameter description for details
175	2093h	47	Analog Input 2 Format	U16	0	6	0: 0...10V 1: 0...20mA 2: t 4...20mA 3: r 4...20mA 4: t 20...4mA 5: r 20...4mA 6: Ptc-th
176	2094h	48	Standby Mode Timer	U16	0	250	1dp, e.g. 250 = 25.0s
177	2095h	49	PI Wake Up Error Level	U16	0	1000	1dp, e.g. 50 = 5.0%
178	2096h	50	User Relay Output Hysteresis	U16	0	1000	1dp e.g. 100 = 10.0%
179	2097h	51	Motor Control Mode	U16	0	4	0: IM Vector 1: V/F 2: PM Motor 3: BLDC Motor 4: SynRM Motor
180	2098h	52	Motor Parameter Autotune	U16	0	1	
181	2099h	53	Vector Mode Gain	U16	0	2000	1dp, e.g. 500 = 50.0%
182	209Ah	54	Maximum Current Limit	U16	0	1750	1dp, e.g. 1000 = 100.0%
183	209Bh	55	Motor Stator Resistance	U16	0	65535	2dp, e.g. 100 = 1.00R
184	209Ch	56	Motor Stator d-axis Inductance (Lsd)	U16	0	65535	1dp, e.g. 1000 = 100.0mH
185	209Dh	57	Motor Stator q-axis Inductance (Lsq)	U16	0	65535	1dp, e.g. 1000 = 100.0mH
186	209Eh	58	DC Injection Speed	U16	0	P-01	3000 = 50.0Hz
187	209Fh	59	DC Injection Current	U16	0	1000	1dp, e.g. 100 = 10.0%
188	20A0h	60	Thermal Overload Retention	U16	0	1	

### 3.5. Additional Information

#### 3.5.1. Drive Control Word Format

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
High byte								Low byte							

Bit 0: Run/Stop command: Set to 1 to enable the drive. Set to 0 to stop the drive.

Bit 1: Fast stop request. Set to 1 to enable drive to stop with 2<sup>nd</sup> deceleration ramp.

Bit 2: Reset request. Set to 1 in order to reset the drive if drive is under trip condition.

User must clear this bit when drive is under normal condition to prevent un-expected reset.

Bit 3: Coast stop request. Set to 1 to issue a coast stop command.

For normal operation, Bit 3 has the highest priority, bit 0 has the lowest priority (bit 3>bit 1>bit 0). For example if user set command as 0x0009, drive will do a coast stop rather than run. For normal run/start, just set this register to 1.

Note that stat/stop (bit 0), fast stop (bit 1) and coast stop (bit 3) only works if P-31= 0 or 1. Otherwise, start/stop function is controlled by drive control terminals. Reset function (bit 2) works all the time as long as drive is operated under Modbus control mode (P-12=3 or 4).

#### 3.5.2. Speed Reference Format (Standard resolution)

Speed reference value is transferred with one decimal place (200 = 20.0Hz). The maximum speed reference value is limited by P-01. Either register 2 or register 5 can be used for speed reference control, however only one reference should be used in any control system, otherwise unexpected behaviour can result.

#### 3.5.3. Acceleration / Deceleration Ramp Time

Active only when P-12 = 4, this register specifies the drive acceleration and deceleration ramp time. The same value is applied simultaneously to the acceleration and deceleration ramp times. The value has two decimal places, e.g. 500 = 5.00 seconds.

#### 3.5.4. High Resolution Speed Reference

This register allows the user to set the speed reference value in the internal format, e.g. 3000 = 50.0Hz. This allows control resolution to 1 RPM with a 2 pole motor. The maximum allowed value is limited by P-01.

Either register 2 or register 5 can be used for speed reference control, however only one reference should be used in any control system, otherwise unexpected behaviour can result.

#### 3.5.5. Drive status and error code Word

High byte gives drive error code. (Valid when the drive is tripped, see 3.5.5 for further details)

Low byte gives drive status information as follows:-

- Bit 0: 0 = Drive Stopped, 1 = Drive Running
- Bit 1: 0 = OK, 1 = Drive Tripped
- Bit 5: 0 = OK, 1 = In Standby Mode
- Bit 6: 0 = Not Ready, 1 = Drive Ready to Run (not tripped, hardware enabled and no mains loss condition)

**3.5.6. Scope Channel Data Values**

These registers show the scope present data sample value for the first two scope channels. The channel data source selection is carried out through Optitools Studio.

**3.5.7. Modbus RTU Registers 25 - 28: Drive Serial Number**

The drive serial number may be read using these four registers. The serial number has 11 digits, stored as follows:-

Register 28		Register 27				Register 26		Register 25		
x	x	x	x	x	x	x	x	x	x	x

e.g.

Register 25	1										
Register 26	1										
Register 27	8745										
Register 28	57										
Drive Serial Number	5	7	8	7	4	5	0	1	0	0	1

**3.5.8. Start Mode, Auto Restart & Fire Mode Configuration (P-30)**

This parameter contains 3 values, stored as follows :-

High Byte								Low Byte							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Input Type 0 : Constant 1 : Momentary Start				Input Sense 0 : Normally Closed (Open Fire Mode) 1 : Normally Open (Closed Fire Mode)				Start Mode / Auto Restart as :- 0 : Edge-r 1 : Auto-0 2 : Auto-1 3 : Auto-2 4 : Auto-3 5 : Auto-4 6 : Auto-5							

**3.5.9. DC Injection Configuration (P-32)**

The parameter value is stored as a combined 16 bit word which is constructed as follows:-

High Byte								Low Byte							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
DC Injection Mode 0 : DC Injection on Start 1 : DC Injection on Stop 2 : DC Injection on Start & Stop								DC Injection Duration : 1dp, e.g. 0 – 250 = 0.0 – 25.0s							

**3.5.10. Communications Configuration (P-36)**

This Register entry contains multiple data entries, as follows:-

High Byte								Low Byte							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Trip Configuration				Baud Rate				Drive Address							

Data values can be interpreted as follows:-

Drive Address	1 to 63		
Baud Rate	Setting	Modbus RTU	CAN Open
	0	115k2	500
	1	115k2	500
	2	9k6	500
	3	19k2	500
	4	38k4	500
	5	57k6	500
	6	115k2	500
	7	115k2	125
	8	115k2	250
	9	115k2	500
10	115k2	1000	
Trip Time Set-up	0	Comms Loss Trip Disabled	
	1	30ms Watchdog, Trip on Comms Loss	
	2	300ms Watchdog, Trip on Comms Loss	
	3	1000ms Watchdog, Trip on Comms Loss	
	4	3000ms Watchdog, Trip on Comms Loss	
	5	30ms Watchdog, Ramp To Stop on Comms Loss	
	6	300ms Watchdog, Ramp To Stop on Comms Loss	
	7	1000ms Watchdog, Ramp To Stop on Comms Loss	
	8	3000ms Watchdog, Ramp To Stop on Comms Loss	

**3.5.11. Display Scaling (P-40)**

The parameter value is stored as a combined 16 bit word which is constructed as follows:-

High Byte								Low Byte							
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Display Scaling Source 0 : Motor Speed 1 : Motor Current 2 : Analog Input 2 Signal 3 : PI Feedback								Display Scaling Factor : 3dp, e.g. 0 – 16000 = 0.000 – 16.000							

### 3.6. Modbus RTU Indirect Parameter Access

Optidrive E3 allows Read / Write access to all user adjustable parameters using a simple method as detailed below. This is achieved using the following two Modbus registers.

#### Register 44: Drive parameter index

This index value will be used by register 45 to carry out parameter read and write function. The valid range of this parameter is from 1 to 60 (maximum number of drive user adjustable parameters)

#### Register 45: Drive parameter value

When reading this register, the value represents the drive parameter value which index is specified by register 44.

When writing to this register, the value will be written to the drive parameter number specified by register 44.

##### 3.6.1. Parameter Read Method

In order to read a parameter, firstly write the parameter number to register 44, then read the value from register 45, e.g. to Read the Value of P-01

- Write 1 to Register 44
- Read the Value of Register 45

##### 3.6.2. Parameter Write Method

Writing parameter values can be achieved by the same method, however Register 45 is used to write the parameter value after the parameter number has been selected using Register 44, e.g. to Write a Value of 60.0Hz to parameter P-01

- Write 1 to Register 44
- Register 45 will return the present value of P-01, which can be Read if required
- Referring to the parameter table shown in 3.4.2, apply any scaling necessary
  - In this case, 60.0Hz = 3600
- Write the scaled value to Register 45. P-01 now changes to 60.0Hz, or an exception code may be returned.


## 4. Diagnostic and Fault Messages

Fault Code	No.	Description
no-Flt	00	No Fault
OI-b	01	Brake channel over current
OL-br	02	Brake resistor overload
O-I	03	Instantaneous over current
I.t-trp	04	Motor Thermal Overload (I2t)
SAFE-1	05	Reserved
O-Volt	06	Over voltage on DC bus
U-Volt	07	Under voltage on DC bus
O-t	08	Heatsink over temperature
U-t	09	Under temperature
P-dEF	10	Factory Default parameters have been loaded
E-trip	11	External trip
SC-ObS	12	Optibus comms loss
FLt-dc	13	DC bus ripple too high
P-LOSS	14	Input phase loss trip
h O-I	15	Instantaneous over current on drive output.
th-Flt	16	Faulty thermistor on heatsink.
dAtA-F	17	Internal memory fault. (IO)
4-20 F	18	4-20mA Signal Lost
dAtA-E	19	Internal memory fault. (DSP)
U-dEF	20	User Default Parameters Loaded
F-Ptc	21	Motor PTC thermistor trip
FAN-F	22	Cooling Fan Fault
O-hEAt	23	Environmental temperature too high
Out-F	26	Drive output fault
AtF-01	40	Measured motor stator resistance varies between phases.
AtF-02	41	Measured motor stator resistance is too large.
AtF-03	42	Measured motor inductance is too low.
AtF-04	43	Measured motor inductance is too large.
Out-Ph	44	Output (motor) phase missing
Out-Ph	49	Output (Motor) phase loss
SC-F01	50	Modbus comms loss fault
SC-F02	51	CANopen comms loss trip







5.3.2. Size 1, IP20, 200-240V, 2.3A, 4.3A & 7A




5.3.3. Size 1, IP66, 200 – 240V, 2.3A, 4.3A & 7A



5.3.4. Size 1, IP20, 380-480V, 2.2A & 4.1A



5.3.1. Size 1, IP66, 380-480V, 2.2A & 4.1A




**5.3.2. Size 2, IP20, 110-115V, 5.8A**

TBC


**5.3.3. Size 2, IP66, 110-115V, 5.8A**

TBC


5.3.4. Size 2, IP20, 200-240V, 7A & 10.5A




5.3.5. Size 2, IP20, 200-240V, 7A & 10.5A




5.3.6. Size 2, IP20, 380-480V, 4.1A, 5.8A, 9.5A




5.3.7. Size 2, IP66, 380 – 480V, 4.1A, 5.8A, 9.5A




5.3.8. Size 3, IP20, 200 – 240 & 380 – 480V, 14A, 18A & 24A



5.3.9. Size 3, IP66, 200 – 240 & 380 – 480V, 14A & 18A



5.3.10. Size 4, IP20, 200 – 240 & 380 – 39-V, 30A, 39A & 46A



## 6. Immunity Tests

### 6.1. Electrostatic Discharge (ESD)

The Optidrive E3 product range has been designed and tested to comply with the limits defined in EN 61800-3:2004+A1-2012. The test techniques used are as defined in EN 61000-4-2:2009.

Application	Test points	Test Method	Level
Direct	Control Terminals	Contact Discharge	±4kV
		Air Discharge	±8kV
	Power Terminals	Air Discharge	±8kV
Indirect	Vertical coupling plane	Contact Discharge	±4kV
	Horizontal coupling plane	Contact Discharge	±4kV

### 6.2. Electrical Fast Transient Burst (EFT/B)

The Optidrive E3 product range has been designed and tested to comply with the limits defined in EN 61800-3: 2004+A1-2012. The test techniques used are as defined in EN 61000-4-4:2004.

Test points	Test Method	Level
Control Terminals	Capacitive clamp	±1kV at 5kHz
Motor Power Terminals	Capacitive clamp	±2kV at 5kHz
1-PH Supply Power Terminals	Coupling Decoupling Network	±2kV at 5kHz
3-PH Supply Power Terminals	Capacitive clamp	±4kV at 5kHz

### 6.3. Surge

The Optidrive E3 product range has been designed and tested to comply with the limits defined in EN 61800-3: 2004+A1-2012. The test techniques used are as defined in EN 61000-4-5:2006.

Drive Type	Test Method	Level
200-240V	Line to Line/Neutral	±1kV
	Line/Neutral to Earth	±2kV
380-480V	Line to Line	±2kV
	Line to Earth	±4kV

### 6.4. Dielectric strength (Flash)

The Optidrive E3 product range has been designed and tested to comply with the limits defined in EN 61800-5-1: 2007. The test techniques used are as defined in EN 61800-5-1: 2007.

Drive Type	Level
200-240V	1.5kV
380-480V	2.5kV



## 7. General Technical and Performance Data

### 7.1. Electrical Data

<b>7.1.1. Mains Supply Details</b>	
Supply Voltage Range	110 Volt Units – 110 – 115 Volt +10% / -10% 230 Volt Units – 200 – 240 Volt +10% / -10% 400 Volt Units – 380 – 480 Volt +10% / -10%
Supply Frequency	48 – 62Hz
Inrush Current	< rated input current
Power Up Cycles	>120x /hr, evenly spaced
Single Phase Operation	Three phase drives can be operated from a single phase supply with 50% derating of the maximum output current
<b>7.1.2. Motor Control</b>	
Output Frequency Range	0 to 500Hz in 0.1 Hz steps Max Output Frequency = Max Switching Frequency / 16.
Output Voltage Range	0 to Supply Voltage
Speed Regulation	Open Loop < 2% motor rated speed
Torque Control	0 – 175% of rated torque, + / -5% accuracy, Response time <10ms
Effective Switching Frequency	Refer to section 2.1
Acceleration Time	0 – 600 seconds, 0.01s resolution
Deceleration Time	Two deceleration ramps 0 – 600 seconds, 0.01s resolution
<b>7.1.3. Overload Capacity</b>	
Overload Capacity	150% of rated current for 60 seconds, repeat cycle every 10 minutes. 175% / 4 seconds

### 7.2. Input Output Current Ratings

#### 7.2.1. 110V Input

Frame Size	Supply Voltage	Power Rating (kW)	Input Current (A)	iTHD (%)	AC Line Choke	Input Current (A)	iTHD (%)	Output Current (A)
1	110V, 1 Ph.	0.37	7.8		OPT-2-L1016-20			2.3
		0.75	15.8		OPT-2-L1016-20			4.3
2	230V, 3ph	1.1	21.9		OPT-2-L1025-20			5.8

The data above is provided to show typical values. Results measured at the point of installation may vary according to the installation site and load conditions Test results are measured under the following conditions:-

- 400 Volt RMS AC Supply Voltage
- Operating IE2 motor with matching power rating according to the drive
- Operated at full rated output current capacity

**7.2.2. 230V Input**

Frame Size	Supply Voltage	Power Rating (kW)	Input Current (A)	iTHD (%)	AC Line Choke	Input Current (A)	iTHD (%)	Output Current (A)
1	230V, 1ph	0.37	3.7		OPT-2-L1016-20			2.3
		0.75	7.5		OPT-2-L1016-20			4.3
		1.5	12.9		OPT-2-L1016-20			7.0
	230V, 3ph	0.37	3.4		OPT-2-L3006-20			2.3
		0.75	5.6		OPT-2-L3006-20			4.3
		1.5	9.5		OPT-2-L3010-20			7.0
2	230V, 1ph	1.5	12.9		OPT-2-L1016-20			7.0
		2.2	19.2		OPT-2-L1025-20			10.5
	230V, 3ph	1.5	8.9		OPT-2-L3006-20			7.0
		2.2	12.1		OPT-2-L3010-20			10.5
3	230V, 1ph	4.0	29.2		-			15.3
	230V, 3ph	4.0	20.9		OPT-2-L3036-20			18
		5.5	26.4		OPT-2-L3036-20			24
4	230V, 3ph	5.5	26.9		OPT-2-L3036-20			24
		7.5	33.3		OPT-2-L3036-20			30
		11	50.1		OPT-2-L3050-20			46

The data above is provided to show typical values. Results measured at the point of installation may vary according to the installation site and load conditions Test results are measured under the following conditions:-

- 230 Volt RMS AC Supply Voltage
- Operating IE2 motor with matching power rating according to the drive
- Operated at full rated output current capacity

**7.2.3. 400 / 460 Volt Input**

Frame Size	Supply Voltage	Power Rating (kW)	Input Current (A)	iTHD (%)	AC Line Choke	Input Current (A)	iTHD (%)	Output Current (A)
1	400V, 3ph	0.75	3.5		OPT-2-L3006-20			2.2
		1.5	5.6		OPT-2-L3006-20			4.1
2		1.5	5.6		OPT-2-L3006-20			4.1
		2.2	7.5		OPT-2-L3006-20			5.8
3		4.0	11.5		OPT-2-L3010-20			9.5
		5.5	17.2		OPT-2-L3036-20			14
		7.5	21.2		OPT-2-L3036-20			18
4		11	27.5		OPT-2-L3036-20			24
		15	34.2		OPT-2-L3036-20			30
		18.5	44.1		OPT-2-L3050-20			39
	22	51.9		OPT-2-L3050-20			46	

The data above is provided to show typical values. Results measured at the point of installation may vary according to the installation site and load conditions Test results are measured under the following conditions:-

- 400 Volt RMS AC Supply Voltage
- Operating IE2 motor with matching power rating according to the drive
- Operated at full rated output current capacity

**7.3. Standby Power Consumption**

The following table shows the power consumption of the drive under the following conditions.

- Drive is powered from the nominal rated mains supply voltage (e.g. 230 or 400 Volt)
- Output disabled
- Cooling fan off
- No external power drawn from the control terminals

Frame Size	Voltage	Phase	Consumption
1	230	1	3.07W
	230	3	3.07W
	400	3	4.55W
2	230	1	4.51W
	230	3	4.51W
	400	3	6.44W
3	230	1	5.16W
	230	3	5.16W
	400	3	6.42W
4	230	3	7.54W
	400	3	14.6W

## 7.4. DC Bus Discharge Time

DC Bus discharge times are based on maximum continuous rated DC bus voltage. In compliance with EN 61800-5-1:2007, all drives have a caution on the rating labels stating "Power down for 5 minutes before removing cover"

Frame Size	Supply Voltage	DC Bus Voltage			Time to reach 50V
		Max	after 5s	after 60s	
1	240Vac +10%	375	323	24.8	26 sec
	480Vac +10%	680	510	36	34 sec
2	240Vac +10%	375	332	27.3	42 sec
	480Vac +10%	680	564	24.5	48 sec
3	240Vac +10%	375	324	36.4	27 sec
	480Vac +10%	680	601	59.6	109 sec
4	240Vac +10%	375	301	28.6	46 sec
	480Vac +10%	680	610	40.2	58 sec

## 7.5. Earth Leakage Current (Touch Current)

The Optidrive E3 product range has been designed and tested to comply with the limits defined in EN 61800-5-1: 2007. The test techniques used are as defined in EN 60990:2000.

As stated in the standard 61800-5-1:2007, 5.2.3.5 the motor does not have to be loaded, however, the motor type, cable type and length can have a significant impact on the results.

Frame Size	Typical Supply Conditions		Maximum Supply Conditions	
	Supply Voltage	I <sub>Touch</sub> (mA)	Supply Voltage	I <sub>Touch</sub> (mA)
1	1ph 230V 50Hz	3.5	1ph 240V +10% 60Hz	4.8
	3ph 230V 50Hz	4.6	3ph 240V +10% 60Hz	7.5
	3ph 400V 50Hz	8	3ph 480V +10% 60Hz	13
2	1ph 230V 50Hz	3.5	1ph 240V +10% 60Hz	4.8
	3ph 230V 50Hz	4.7	3ph 240V +10% 60Hz	7.2
	3ph 400V 50Hz	8.1	3ph 480V +10% 60Hz	12.6
3	1ph 230V 50Hz	3.5	1ph 240V +10% 60Hz	4.7
	3ph 230V 50Hz	4.7	3ph 240V +10% 60Hz	6.8
	3ph 400V 50Hz	8.1	3ph 480V +10% 60Hz	12.7
4	3ph 230Vac 50Hz	4.8	3ph 240V +10% 60Hz	6.9
	3ph 400Vac 50Hz	8.2	3ph 480V +10% 60Hz	12.9

### NOTE

The Touch Current value is based on:-

- Normal operating conditions, i.e. all phases balanced and connected correctly with the motor running
- Drive fitted with integrated EMC filter

## 7.6. Digital & Analog I/O

### 7.6.1. Digital Inputs Specification

Voltage Range 8 – 30 V dc, Internal or External supply, NPN (positive logic)  
Response Time < 8ms

### 7.6.2. Analog Inputs Specification

Range Current : 0-20mA, 4-20mA. 20mA max input current  
Voltage: -10-10V (Analog Input 1 Only), 0-10V, 0-5V, 0/24V, 30V max input  
Resolution Analog Input 1: 12-bit, <16ms response time (Uni-Polar)  
Analog Input 2: 12-bit, <16ms response time (Uni-Polar)  
Accuracy better than 1% of full scale  
Scaling & Offset Parameter adjustable

### 7.6.3. Analog Output Specification

Range Current : 0..20mA, 4..20mA, 20mA max  
Analog : 0..10V, 0 / 24V (digital), 20mA max  
Resolution 10-bit  
Accuracy better than 1% of full scale

### 7.6.4. Relay Output

Maximum Switching Voltage : 250VAC, 30 VDC  
Maximum Switching Current : 5A at 30 Volt DC, 6A at 250 Volt AC

## 7.7. Environmental Data

<b>7.7.1. Temperature Range</b>		
Ambient Temperature Range : Operation	IP20 Drives : -10 - +50°C (14 - 122°F) without derating IP55 & IP66 Drives : -10 - + 40°C (14 - 104°F) without derating	
Note : No frost or condensation permissible		
Ambient Temperature Range : Storage	-40 ... 60 °C. No Frost or Condensation	
<b>7.7.2. Altitude</b>		
Maximum Altitude (No derating)	1000m Derate above 1000m by 1% per 100m	
Maximum Altitude (UL Approved)	2000m	
Maximum Altitude	4000m	
<b>7.7.3. Relative Humidity</b>		
Relative Humidity Limit	95% Maximum, non-condensing	
<b>7.7.4. Contamination Levels</b>		
Standard	IEC 721-3-3, Non-conductive dust allowed	
Transportation	Class 1C2 (chemical gases), Class 1S2 (solid particles)	
Storage	Class 2C2 (chemical gases), Class 2S2 (solid particles)	
Operation	Class 3C2 (chemical gases), Class 3S2 (solid particles)	
<b>7.7.5. Vibration Levels</b>		
Shock Test	Pulse Shape Peak Acceleration Duration Axes Tested Number of Shocks Configuration	Half-Sine 15g 11ms 3 Orthogonal 3 in each direction (18 in total) Non-operational throughout
Sinusoidal vibration test	Frequency Range Severity  Sweep Rate Axes Tested Number of Cycles Configuration	10Hz – 150Hz 10Hz – 57.55Hz: 0.15mm peak-peak displacement 57.55Hz – 150Hz: 1g peak acceleration 1 octave/minute 3 Orthogonal 10 cycles/axis (1 cycle consists of an up and a down sweep) Non-operational throughout

## 7.8. Response Times

Command Source	Response Time
Digital Input	<8ms
Analog Input	<16ms
Modbus RTU Interface	<8ms From receipt of valid command
CAN Open Interface	<8ms From receipt of valid command
Master / Slave Function	<8ms, response, 60ms cycle
Power Stage	<10ms to enable output

## 7.9. Motor Control Performance

### 7.9.1. V/F Mode

Speed Regulation : + / - 20% of motor slip with slip compensation enabled

### 7.9.2. Vector Mode

Static Speed Accuracy : + / - 0.033%

Speed Regulation 0 – 100% Load Range : + / - 1%

Torque Response : 1- 8ms

Torque Linearity (10 – 90% of motor rated speed, 20 – 100% load torque range) : + / - 5%

## 7.10. Output Current Limit

### 7.10.1. Overload Operation

Optidrive E3 provides the following

- 150% Output current / 60 Seconds Maximum
- 175% Output current / 3.75 Seconds Maximum

At low output frequency levels, overload accumulation is faster, to account for the reduced motor cooling effect of the fan.

**7.10.2. Overview**

Optidrive E3 features both hardware and software protection of the output stage to prevent damage. In addition, an Ixt system is used to monitor motor overload condition and prevent damage to the motor due to operation for prolonged periods at high load.

I x t protection is software based, using the value for motor rated current programmed in P-08. An internal accumulator register is used to estimate the point at which damage may occur to the motor, and operates as follows

Motor Current < P-08

The accumulator value reduces towards zero. The time required depends on the actual load current as explained further below.

Motor Current = 100% P-08

The accumulator value remains static.

Motor Current > 100% P-08 < 150% P-08

The accumulator value increases at a rate proportional to the overload level, e.g. (Motor Current / Rated current) – 100%. If the overload limit is reached, the drive will trip, displaying it.trp. to protect the motor.

Motor Current > 150% P-08

For high current levels, the accumulator operates 16 times faster than for current levels below 150% of P-08.


Peak over current trip levels are shown in the table below.

**7.10.3. Example Operation**

Maximum overload operation is 150% of motor rated current for 60 seconds. As this represents an overload of 50%, the accumulator trip level is 3000. This means that if the drive operates with 125% load current, the time can be calculated as 3000 / (125 – 100) = 120 Seconds.

Above 150% load, accumulation is 16 times faster, hence for 160% load current, the time is 3000 / 16 / (160 – 150) = 18.75 seconds

**7.10.4. Overload Curve**



**7.11. Under / Over Voltage Trip Levels**

The following levels are not user adjustable, and define the operating voltage levels of the drive and brake chopper circuit.

Drive Rated Supply Voltage	Drive Type	DC Bus Voltage Level (Volts DC)				
		Brake Chopper On	Brake Chopper Off	Under Voltage Trip	Minimum Operating (Inrush Disabled)	Over Voltage Trip
110 – 115 Volts AC	Single Phase Output	195	189	80	113	208
110 – 115 Volts AC	Voltage Doubler	390	378	160	239	418
200 – 240 Volts AC	All	390	378	160	239	418
380 – 480 Volts AC	All	780	756	320	478	835





**Optidrive E3 Advanced Technical Manual Issue 02**